



smartset® cd
alarm clock radio



Brookstone®



SMARTSET® CD ALARM CLOCK RADIO

Brookstone makes life better.


Our **SmartSet® CD Alarm Clock Radio** is the world's first and only LED CD clock radio that automatically sets itself to the correct year, month, date, day and time as soon as you plug it in. The only thing you have to do is input your time zone, and the built-in computer does everything else for you. You can even wake to your favorite CD or radio station.

The SmartSet® CD Alarm Clock Radio has been thoroughly tested to be certain it meets our own exacting quality control standards. Please take a few moments to review the following important information before using it.

Perfect time—all the time!

CAUTION

TO PREVENT FIRE OR SHOCK HAZARD, DO NOT USE THIS PLUG WITH AN EXTENSION CORD, RECEPTACLE OR OTHER OUTLET UNLESS THE BLADES CAN BE FULLY INSERTED TO PREVENT BLADE EXPOSURE.
TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS UNIT TO RAIN OR MOISTURE.



IMPORTANT SAFETY INSTRUCTIONS

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with a dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong is provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
11. Only use attachments/accessories specified by the manufacturer.
12. Unplug this apparatus during lightning storms or when unused for long periods of time.

13. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
14. This appliance should not be exposed to dripping or splashing water and no object filled with liquids such as a vase should be placed on the apparatus.
15. Do not overload wall outlet. Use only power source as indicated.
16. Use replacement parts as specified by the manufacturer.
17. The product may be mounted to a wall only if recommended by the manufacturer.
18. Upon completion of any service or repairs to this product, ask the service technician to perform safety checks.

Thank you for purchasing this Brookstone® CD Alarm Clock Radio with the patented SmartSet® automatic time-setting system. As soon as you plug in your radio for the first time, and after every power interruption, the clock will automatically set itself to the correct year, month, date, day, and time. It will also automatically adjust itself for all Daylight Saving Time changes through the year 2099.

There are dual alarms that can be set and used independently. The alarms can be set for weekdays only, weekends only or everyday operation. You can wake to an electronic buzzer tone, your favorite

AM or FM station or a specific track on your favorite CD. And if you can't reach the Snooze Bar when the alarm goes off, you can just wave your hand in front of the "Touchless" snooze sensor on the front panel. The alarm will shut off for nine minutes and then turn on again. There's a programmable 99-minute sleep timer that allows you to fall asleep to up to 99 minutes of music and then shuts the power off automatically.

A programmable 99-minute nap timer wakes you up after a nap without disturbing your normal alarm settings.

The CD player has a 20-track programmable memory and repeat playback. It will also play CD-R and CD-RW discs in addition to normal CDs. The digital tuning stereo receiver locks in your favorite stations perfectly and stores up to 20 stations (10 AM and 10 FM) in memory for immediate recall.

This model also includes a battery back-up system. There's a built-in CR2430 lithium battery that will maintain the time and alarm settings for up to five years or longer, depending on the frequency and length of the power interruptions you experience in your home. We've also provided a SureAlarm® battery back-up system that will activate the alarm even if the power is off at your wake-up time. The SureAlarm circuit requires a 9-volt battery (not included).

The time, radio frequency and CD track number all appear on a large super-bright LED display that is easily readable from anywhere in your room. And we've included a dimmer switch in case you want to reduce the display brightness for sleeping.

With so many useful features packed into such a compact unit it's imperative that you read this Owner's Manual carefully and completely.


Your SmartSet's serial number is located on a label on the bottom of the cabinet. Please take a moment to locate the serial number of your unit and write it in the space provided below. You may be asked to provide this number when calling to request customer service.

Serial Number: _____

IMPORTANT NOTES

- Avoid installing this unit in places exposed to direct sunlight or close to heat radiating appliances such as electric heaters, on top of stereo equipment that radiates too much heat, places lacking ventilation or dusty areas, places subject to constant vibration and/or humid or moist areas.
- Do not attempt to clean this unit with chemical solvents as this might damage the finish. Use a clean dry cloth.
- Operate controls and switches as described in the manual.
- Before turning 'On' the power, make certain that the power cord is properly installed.
- Store CDs in a cool area to avoid damage from heat.
- When moving the unit, be sure to first disconnect the power cord.

CLASS 1 LASER PRODUCT



FCC INFORMATION

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

PREPARATION FOR USE

Unpacking and Set-Up

1. Remove the unit from the shipping carton and remove all packing material from the unit. Please save the carton and packing material if possible in the event that your unit ever needs to be returned for service. Using the original carton and packing materials is the only way to protect your unit from damage in transit.
2. Carefully remove any small strips of tape that may have been used to keep the CD door closed during shipment.
3. Press on the CD door in the area marked OPEN/CLOSE to open the door. Inside the CD compartment you will see a white “dummy CD” transit protection card. This card prevents the laser pick-up from moving during shipment and it must be removed before you can load your own CDs. Carefully remove this transit protection card and discard it.

4. Place the unit on a stable, level surface such as a table, desk, shelf, or stand, out of direct sunlight and away from sources of excess heat, dust, vibration, moisture, or humidity, and convenient to a 120V 60Hz AC outlet.
5. Unwind the AC power cord and extend it to its full length. This is important. The FM antenna is built into the AC power cord.

Battery Back-Up Systems

This model has two separate battery back-up systems. There is a built-in 3-volt CR2430 long-life lithium battery that will maintain the clock settings, the alarm settings and the tuner preset memory settings. The lithium battery may last for up to five years or even longer, depending on the frequency and length of the power interruptions that you experience in your home. If AC power is interrupted, the display will go off but the lithium battery will continue to power the clock. When AC power is restored, the display comes on again and all your settings will be correct. If you have installed a 9-Volt battery and the power is 'off' at the wake-up time, the buzzer alarm will still turn on to wake you up, even if the alarm selector was set to 'Wake To Radio.'

Note: During a power interruption, the 'Wake to CD' alarm will not operate.

We have also provided a separate SureAlarm battery back-up circuit that requires a 9-volt battery (not included). If you install a 9-volt battery, the alarm will operate even if the power is off at the selected wake-up time.

Installing The SureAlarm Back-up Battery (Not Included)

The SureAlarm battery compartment is located on the back panel.


1. Press down on the battery door locking tab as shown and remove the battery door.
2. Gently pull the battery terminal outside of the compartment just far enough so you can connect the battery.
3. Connect a fresh, 9-volt alkaline battery to the battery terminal. It can only be connected one way.
4. Push the battery back into the battery compartment and replace the battery door.




Low Battery Indicator

The Low Battery indicator  **LOW** only appears in the main display when the unit is in the power 'Off' mode.


- If you install a 9-volt battery in the SureAlarm circuit as described above, the Low Battery indicator disappears.



- If the Low Battery indicator remains 'On', this indicates that either you have not installed the 9-volt battery, or that the 9-volt battery is exhausted and needs to be replaced.



- If the Low Battery indicator flashes, this indicates that the 3-volt lithium battery is getting weak and should be replaced as soon as possible.




Instructions for changing the lithium battery will be found on pages 48-51 of this manual.

Power Source

This system is designed to operate on 120V AC 60Hz house current only. Connecting this system to any other power source may cause damage to the system and such damage is not covered by your warranty.


Note: The system has a polarized AC plug with one wide blade and one narrow blade. The plug will only fit into matching polarized AC outlets.



This is a safety feature to reduce the possibility of electric shock. If the plug will not fit in your AC outlet, you probably have an outdated non-polarized outlet. You should have your outdated outlet changed by a qualified, licensed electrician. Do not file the wide blade on the plug, or use an adapter to make the plug fit into your outlet. This defeats the safety feature and could expose you to electric shock.

Protect Your Furniture

This model is equipped with non-skid rubber 'feet' to prevent the product from moving when you operate the controls. These 'feet' are made from non-migrating rubber material specially formulated to avoid leaving any marks or stains on your furniture. However, certain types of oil-based furniture polishes, wood preservatives, or cleaning sprays may cause the rubber 'feet' to soften, and leave marks or a rubber residue on the furniture. To prevent any damage to your furniture, we strongly recommend that you purchase small self-adhesive felt pads, available at hardware stores and home improvement centers everywhere, and apply these pads to the bottom of the rubber 'feet' before you place the product on fine wooden furniture.



LOCATION OF CONTROLS AND INDICATORS

1. Speakers
2. TOUCHLESS SNOOZE SENSOR
3. Multi-Function LED Display
4. 3-Volt Lithium Battery Compartment (Bottom Cabinet)
5. POWER ON/OFF Button
6. SLEEP Button
7. ALARM 1 (BUZZER/RADIO/CD/OFF) Selector Switch
8. ALM (Alarm) 1 Button
9. ALARM 2 (BUZZER/RADIO/CD/OFF) Selector Switch
10. DIMMER (LO/HI) Selector Switch
11. 9-Volt Battery Compartment (Back Cabinet)
12. AC Power Cord
13. CD Door
14. PRESET + Button
15. ◀◀ REV. SKIP/TUNING – Button
16. ▶▶ FWD. SKIP/TUNING + Button
17. VOLUME Control
18. ▶|| PLAY/PAUSE Button
19. ■ STOP Button
20. WAKE UP TRACK Button

21. MEMORY Button
22. PRESET – Button
23. AM/FM Button
24. REPEAT Button
25. NAP Button
26. PROGRAM Button
27. SNOOZE/SLEEP/NAP OFF Button
28. TIME Button
29. MONTH/DATE Button
30. TIME ZONE Button
31. ALM (Alarm) 2 Button
32. ALARM MODE Button

OPERATING INSTRUCTIONS


- Make sure that you have extended the AC power cord to its full length. The FM antenna is built into the power cord.
- Make sure that you have installed a fresh 9-volt battery in the SureAlarm circuit if you want the SureAlarm battery back-up circuit to operate. If you do not install a 9-volt battery, the low battery indicator will remain 'on,' but this will not affect any other functions or operation of the unit.
- Make sure you have removed the "dummy CD" transit protection

card from the CD compartment.

A Word About the ◀◀ and ▶▶ Controls

In order to minimize the number of controls on this model, a few of the controls perform more than one function.

For example, the ◀◀ and ▶▶ buttons on the top panel perform the following functions:



- When pressed together with the TIME ZONE button, the ◀◀ and ▶▶ buttons allow you to select a lower- or higher-numbered time zone.
- When pressed together with the TIME button, the ◀◀ and ▶▶ buttons adjust the time display back or forward.
- When pressed together with the ALM 1 or ALM 2 buttons, the ◀◀ and ▶▶ buttons adjust the wake up time display back or forward.
- When pressed together with the MONTH/DATE button, the ◀◀ and ▶▶ buttons adjust the Month and Date display back or forward.
- When pressed together with the TIME and MONTH/DATE buttons, the ◀◀ and ▶▶ buttons adjust the year display back or forward.
- When pressed together with the SLEEP or NAP buttons, the ◀◀ and ▶▶ buttons adjust the amount of Sleep Time or Nap Time display down or up.

- In Tuner mode (AM/FM) pressing the **◀◀** and **▶▶** buttons moves the tuner display down or up to lower- or higher-numbered frequencies.
- In CD mode pressing the **◀◀** and **▶▶** buttons allow you to skip to lower and higher numbered tracks, or to search forward or back within a track to locate a specific musical passage.

All of the functions of the **◀◀** and **▶▶** buttons will be fully explained in the appropriate sections of this manual.

Setting The Time, The First Time

IMPORTANT: The first time you connect your new SmartSet® CD Alarm Clock Radio to the AC outlet the internal computer will automatically set the time correctly for the Eastern Time Zone, which is the initial default setting. The display will scan for a few seconds and then show the correct Day and Time in the Eastern Zone. If you live in the Eastern Time Zone, there's nothing else to do. Your clock is set correctly and running.

If you do not live in the Eastern Time Zone, you must change the default zone display to your own zone. You only do this one time and the SmartSet® will remember the new default zone setting and will always return to that setting after a power interruption.

There are 7 time zones programmed into your SmartSet® CD Alarm Clock Radio as follows:

ZONE 1—Atlantic Time

ZONE 2—Eastern Time (Default Setting)

ZONE 3—Central Time

ZONE 4—Mountain Time

ZONE 5—Pacific Time

ZONE 6—Yukon Time

ZONE 7—Hawaiian Time

To change the default time zone display, depress the TIME ZONE button. The number “02” will appear on the display indicating that the default zone is ZONE 2, Eastern Time.

Hold the TIME ZONE button and then press either the ►► or ◄◄ buttons until your own time zone appears on the display, then release the buttons.

The clock display will change to the correct time in the time zone you selected. The clock will always return to the correct time in the zone you selected after every power interruption. If you move to a different time zone, simply change the default zone display to the new zone and the SmartSet® will remember that setting for you.

Date Display

To see the correct date at any time, depress the MONTH/DATE button. The display changes from time to month and date (MM/DD).

For example, May 21st will appear as "5 21".

When you release the MONTH/DATE button, the display returns to the correct time.



Year Display

To see the correct year, depress the MONTH/DATE and TIME buttons together, the display changes from time to year.

When you release the MONTH/DATE and TIME buttons, the display returns to the correct time.



Daylight Saving and Leap Year Adjustments

All Daylight Saving and Leap Year adjustments are made automatically by the SmartSet® internal computer as follows:

- Start of Daylight Saving Time

At "2:00" AM on the 2nd Sunday in March, the clock will automatically advance to "3:00" AM.

- End of Daylight Saving Time
At "3:00 AM" on the 1st Sunday in November, the clock will automatically reset to "2:00 AM."
- Leap Year
At 12:00 Midnight on February 28th, the calendar display will change to "2 29."

Manual Time Adjustments

Some people like to set their clocks 5 to 10 minutes fast to make sure they will always be on time. Even though the SmartSet® sets the time by itself, you still have the option of adjusting the time manually if you wish.

To manually adjust the time display, depress and hold the TIME button, and press either the ►► or ◄◄ button to adjust the time display ahead or back as desired. Each press of the ►► or ◄◄ buttons will change

the display by one minute. If you hold the ►► or ◄◄ buttons the display will continue to change. The display will change slowly at first, one minute at a time. But if you continue holding the ►► or ◄◄ buttons, the display will change rapidly.

Note: If you manually adjust the time, your new setting is entered into the SmartSet® memory. If the power is interrupted, the display will return to your new setting, not the original setting, when the power is restored.

Adjusting The Wake Up Times

Your SmartSet® CD Alarm Clock Radio has two separate alarms that can be set and used independently. You may use the alarms to wake two people at different times, or you may use one alarm for weekdays and the other for weekend wake-up times.

The procedure for adjusting the wake-up time is the same for both Alarm 1 and Alarm 2.

1. Depress and hold either the ALM 1 or ALM 2 setting button. The display will change from the correct time to the Alarm 1 or Alarm 2 wake up time.



2. While holding the ALM 1 or ALM 2 setting button, depress either the ►► or ◄◄ button to move the display ahead or back to your desired wake up time.
3. When the desired wake up time appears on the display, release the ►► or ◄◄ buttons.

Note: Be sure that you have set the wake-up time correctly by observing the AM indicator. If the AM indicator is 'On,' the wake-up time is "AM". If the AM indicator is 'Off,' the wake-up time is "PM".

4. When the desired wake-up time (AM or PM) appears on the display, release the ALM 1 or ALM 2 setting buttons.

Selecting The Alarm Mode

Your SmartSet® CD Alarm Clock Radio allows you to select from among three different alarm operation modes for either alarm. The alarm modes are:

- Everyday—the alarm will turn on all seven days;
- Weekdays only—the alarm will only turn on Monday through Friday;
- Weekends only—the alarm will only turn on Saturday and Sunday.

To check the Alarm Mode setting for Alarm 1, depress the ALM 1 setting button. The display will show the Alarm 1 wake-up time, and the day of the week indicators will show you the alarm mode which is selected.

- If all seven indicators are 'On,' the Everyday mode is selected.
- If only the Monday through Friday indicators are 'On,' the Weekdays only mode is selected.
- If only the Saturday and Sunday indicators are 'On,' the Weekends only mode is selected.

To change the Alarm Mode setting for Alarm 1, hold the ALM 1 setting button and press the ALARM MODE button until the day indicators show the desired mode setting: Weekdays only, Weekends only, or Everyday operation.

Release the ALARM MODE and ALM 1 setting buttons and the display will return to the correct time.

Follow the same procedure to select the desired Alarm Mode for Alarm 2 if necessary.

Checking The Wake-Up Times And Alarm Mode

Whenever you want to check the wake-up time or the alarm mode settings, simply press either the ALM 1 or ALM 2 setting buttons. The display will change from correct time to wake-up time and the day indicators will show you the alarm mode which is currently selected. Release the ALM 1 or ALM 2 setting buttons to return to correct time.

Listening To The Radio

1. Press the POWER ON/OFF button on the top panel. The display will change from time to radio frequency. The first time you turn your unit on, the display will show FM 87.5 MHz.
2. To switch between the FM and AM bands press the AM/FM button. The first time you select the AM band the display will show AM 520 KHz.
3. Tune to the desired station with the ►► or ◄◄ buttons on the top panel as follows:
 - Manual Tuning
Repeatedly press either the ►► or ◄◄ button until the display shows the frequency of the desired station.
 - Automatic Tuning
Depress and hold either the ►► or ◄◄ button until the display begins to move, then release the button. The tuner searches down or up until it finds a strong signal and then stops on that station. Repeat this process until the tuner stops on the desired station.

4. If you tuned to a FM Stereo station, the FM ST indicator appears in the display.
5. Five seconds after you release the ►► or ◄◄ button the display automatically changes from radio frequency back to the time.



To see the station frequency again, press the TIME button. The display will change from time to radio frequency for five seconds and then return to the time

6. Adjust the VOLUME control on the right side of the cabinet to the desired level.
7. When you are finished listening, press the POWER ON/OFF button to shut the power 'Off'.

Note: The tuner remembers the last station that was tuned before the power was switched off and automatically returns to that station when the power is switched on again.

Presetting Stations In The Tuner Memory

You can store a total of 20 stations, 10 FM and 10AM, in the tuner memory for easy recall at any time.

1. Using either the Automatic or Manual Tuning method described above, tune to the first station you wish to store in the tuner memory.

Example: FM 92.5 MHz



2. When the desired frequency appears on the display, press the MEMORY button once.

"F 1" will begin flashing on the display indicating that you can now store your station in FM Preset Memory number 1.



3. Press the MEMORY button again. The flashing "F 1" disappears and the station frequency returns to the display. This indicates that FM 92.5 is now stored in FM Preset Memory number 1.

4. Tune to the next station that you wish to store.

Press the MEMORY button once, then press PRESET + button to select Preset Memory number 2.

"F 2" begins flashing in the display.



5. Press the MEMORY button once more to enter your desired station in Preset Memory number 2.
6. Repeat steps 4 and 5, using the PRESET + or - buttons to select a different preset memory number each time until you have stored up to 10 FM stations in memory.
7. Press the AM/FM button to switch to the AM band and repeat the above procedure to store up to 10 AM stations in the tuner memory.

Notes:

- The FM memories are numbered F1 through F10. The AM memories are numbered A1 through A10.
- After you press the memory button the first time, you must select a Preset Memory number and press the MEMORY button again within 10 seconds, while the memory number is flashing, or the station will not be memorized.

Recalling Preset Stations


Press the AM/FM button to select the desired band.

Press PRESET + or - buttons to scroll through the preset stations one by one.

Changing Preset Stations

1. Tune to the new station that you want to store.
2. Press the MEMORY button and then press the preset number button to select the memory number that you wish to change.
3. When the desired preset memory number is flashing, press the MEMORY button again. The new station is now stored and the previous station is deleted from the memory.

FM—The FM antenna is built in the AC power cord. You may have to extend and vary the direction of the AC power cord until you find the position that provides the best reception.



AM—The AM bar antenna is inside the cabinet of the main unit. You may need to change the position of the main unit until you find the position that provides the best reception for your favorite AM stations.




Playing CDs

Important: This CD player can play normal CDs plus CD Recordable (CD-R) and CD Rewriteable (CD-RW) discs. However the playability of CD-R/RW discs may be affected by the type of software that was used in 'ripping' the tracks from the original discs and 'burning' the tracks onto the blank media. Playability may also be affected by the quality and condition of the blank media you use for recording. 100% compatibility cannot be guaranteed. This is not an indication of any problems with your player.


1. Press the POWER ON/OFF button to switch the unit 'On.' If you were previously listening to the radio, the unit will return to the last station that was tuned before the power was switched off.
2. Press on the CD door in the area marked OPEN/CLOSE to open the CD door. When the door opens, if you have not already done so, remove the white "dummy CD" transit protection card and discard it.
3. Place your CD on the center spindle with the printed label side facing up and close the CD door.



4. Press the ►|| PLAY/PAUSE button on the top panel.
5. The display briefly shows "Cd" and then two dashes "—" will appear as the player reads the disc.



After a few seconds the display will show the total number of tracks on the disc, then playback begins on Track 1.



After five seconds of playback the display will return to the correct time but the small "CD" and "PLAY" indicators remain in the display to indicate that a CD is playing.



Note: If your disc is dirty, heavily scratched, or otherwise unreadable, the display will continue to show two dashes “--” but playback will not begin.

6. Adjust the VOLUME control to the desired level.
7. Playback will continue until the last track has played, then the player stops, the display briefly shows the total number of tracks, then returns to the correct time again. To stop playback before the disc ends press the ■ STOP button at any time.
8. Press on the CD door in the area marked OPEN/CLOSE to open the CD door, remove your disc, and close the door again.
9. Press the POWER ON/OFF button to shut the system ‘Off.’

Notes:

- If you shut the power off while a CD is playing and you leave the disc in the player, the disc will start playing from track 1 when you switch the system ‘On’ again.
- To see the track number that is playing, press the TIME button once. The display will show the track number for five seconds and then return to the correct time display.

Pause Control

To pause CD playback temporarily, press the **▶||** PLAY/PAUSE button. The display will briefly show the track number that is paused and then returns to the correct time.



The sound stops but the disc continues to spin and the PLAY indicator flashes.

To cancel Pause mode and resume playback press the **▶||** PLAY/PAUSE button again. The sound returns and the PLAY indicator stops flashing.

Skip/Search Controls (◀◀ / ▶▶)

- To skip to higher- or lower-numbered tracks during playback, press the **◀◀** or **▶▶** buttons repeatedly until the desired track number appears in the display. Playback will begin on the desired track.
- To search within a track to locate a specific musical passage, depress and hold the **◀◀** or **▶▶** button. The player will search back or forward at high speed. When you hear the desired passage, release the **◀◀** or **▶▶** button and normal playback will resume at that point.

Note: The Volume level is automatically reduced during high-speed music search.

REPEAT Playback

You can repeat a single track or the entire disc continuously. Repeat playback can be selected while a disc is playing or while the disc is stopped.

Single Track Repeat

Press the ◀◀ or ▶▶ buttons to select the track to be repeated. If necessary, press the ▶|| PLAY/PAUSE button to begin playback, and then press the REPEAT button once.

The Repeat indicator “REP” flashes and the selected track will be repeated continuously.



All Tracks Repeat

Press the REPEAT button twice.

The Repeat “REP” indicator remains ‘On.’ If necessary, press the ▶|| PLAY/PAUSE button to begin playback. All the tracks on the disc will be repeated continuously.



To cancel Repeat Playback press the REPEAT button until the Repeat "REP" indicator disappears.

Normal playback will resume. Repeat Playback is also canceled by pressing the ■ STOP button.

Programmed Playback

Programmed playback allows you to program the player to play up to 20 tracks on a disc in any desired order. You may also program the same track to play multiple times within the same program if desired.

Note: You cannot program the player while the disc is playing. If the disc is playing press the ■ STOP button first and then perform the following steps.

1. Press the PROGRAM button. The Program "PROG" indicator and Track number "0" begin flashing in the display.
2. Press the ◀◀ or ▶▶ buttons to select the first track to be programmed. Example: Track 7
3. When track number 7 is flashing in the display press the PROGRAM button again to enter track number 7 in program memory number 1. The track number display returns to "0."



4. Press the **◀◀** or **▶▶** buttons to select the next track number to be programmed, and when the desired track number is flashing on the display press the PROGRAM button to enter that track in the program memory.
5. Repeat step 4 until you have entered up to 20 tracks in the program memory.
6. Press the **▶||** PLAY/PAUSE button to begin programmed playback. The PLAY indicator appears and the Program "PROG" indicator continues to flash.
The tracks you programmed will be played in the desired order.
7. After the last programmed track has played the player stops and the PLAY and Program "PROG" indicators go 'Off.' However the program sequence remains in the memory.
To play the programmed sequence again press the PROGRAM button and then press the **▶||** PLAY/PAUSE button.
If you press the **▶||** PLAY/PAUSE button without pressing the PROGRAM button, normal playback will begin on Track 1 as usual.
8. To cancel the programmed sequence from the memory, press the **■** STOP button while the player is at programming mode.
The programmed sequence is also canceled if the CD door is opened, the Tuner mode is selected or the power is switched off.



Programmed Repeat Playback

You can use the Repeat and Programmed Playback features together to continuously repeat a programmed sequence of tracks if desired.

First program the desired tracks and start playback following steps 1 through 6 under *Programmed Playback*.

Then press the REPEAT button twice to select All Tracks Repeat. The programmed sequence will be repeated continuously.



Alarm Operation

The dual alarms in this system give you the option of waking to the radio, an electronic buzzer tone, or a track on your favorite CD.

You may also program one or both of the alarms for weekdays only, weekends only, or everyday operation.


Before activating the alarms, first check the settings for Alarm 1 and Alarm 2 and adjust if necessary.

Refer to *Adjusting The Wake Up Times* and *Selecting The Alarm Mode*.

Wake To Radio

1. Tune to the station that you want to wake you up, adjust the VOLUME control to the desired level, then shut the system 'Off.'
2. Slide the ALARM 1 and/or ALARM 2 selector switches located on the left side panel to the "RADIO" position.

The AL 1 and/or AL 2 indicators on the front panel will appear on the display to confirm that the alarms are on.



3. At the selected wake-up time the radio will turn on to the selected station. It will play for one hour and then shut off automatically and reset itself for the following day.

To shut the radio off sooner, you can press either the POWER ON/OFF button or the appropriate ALM 1 or ALM 2 button on the top panel.

Wake To Buzzer (Crescendo Alarm)

Note: Alarm 1 and Alarm 2 have different buzzer sounds.

Alarm 1 is a “single beep” sound.

Alarm 2 is a “double beep” sound.

You will be able to tell which alarm is going off by the sound that it makes.

1. Slide the ALARM 1 and/or ALARM 2 selector switches, located on the left side panel to the “BUZZER” position.

The AL 1 and/or AL 2 indicators on the front panel will light to confirm that the alarms are ‘On.’

2. At the selected wake-up time the electronic buzzer tone alarm will come on. It will start softly and gradually increase in volume to wake you gently.

The buzzer sound will continue for one hour and then shut off automatically and reset itself for the following day.

To shut the buzzer off sooner, you can press either the POWER ON/OFF button or the appropriate ALM 1 or ALM 2 button on the top panel.

Wake To CD

1. Load the desired CD in the player, start playback and adjust the VOLUME control to the desired wake up level. Then shut the power ‘Off.’

- Slide the ALARM 1 and/or ALARM 2 selector switches, located on the left side panel to the "CD" position. The AL 1 and/or AL 2 indicators will appear in the main display to confirm that the alarms are 'On.'



- If you wish to select a specific track to wake you up, depress and hold the WAKE UP TRACK button on the top panel and press the ◀◀ or ▶▶ buttons to select the desired track. When the desired track number appears on the display release all the buttons.

Note: If you do not select a specific track for wake-up, Track 1 is selected automatically. The wake-up track number you selected remains in the memory until you change it by selecting a different track, or the CD door is opened.



- At the selected wake-up time the CD player will turn on to your selected track or to Track 1 if no track was selected.

It will play for one hour or until the end of the disc, whichever comes first, and then shut off automatically and reset itself for the following day.


To shut the CD player off sooner you can press the POWER ON/OFF button or the appropriate ALM 1 or ALM 2 buttons on the top panel.

To Cancel The Alarms

To cancel the alarms completely so they do not come on at all, slide the appropriate ALARM 1 and/or ALARM 2 selector switches to the 'Off' positions.

SNOOZE Alarm

When the alarms turn on in the morning you can activate the SNOOZE control to catch a few minutes extra sleep. The Snooze function stops the alarm for nine minutes and then turns the alarm 'On' again.



There are two ways to activate the Snooze control: by touching the SNOOZE button on the top panel; or by placing your hand in front of the SNOOZE Sensor on the front panel.



When the Snooze function has been activated, the appropriate AL 1 or AL 2 indicator flashes in the display.

Note: The Snooze Sensor detects the difference in temperature between your hand and the ambient room temperature and it is quite accurate.

However in the unusual condition where there is almost no difference between your hand temperature and the room temperature the touchless snooze function may not operate. In this case, press the SNOOZE button on the top panel.

SLEEP Timer

The Sleep Timer allows you to operate the radio or CD player for up to 99 minutes while you are falling asleep and then shuts the power off automatically.



1. Turn the system 'On' and operate the radio or CD player as usual.
Adjust the VOLUME control to the desired level for falling asleep, but remember that the level you set for falling asleep is that same level that you will hear in the morning if you are waking to the radio or a CD.
2. Press the SLEEP button on the top panel.
The display will show "L:30" and the SLP (Sleep) indicator will appear.
The radio or CD player will operate for 30 minutes and then shut off automatically.
3. To change the amount of Sleep time depress and hold the SLEEP button and press the ◀◀ or ▶▶ buttons to decrease or increase the amount of sleep time from two minutes to 99 minutes.

Note: When you change the Sleep timer from the original 30-minute default setting, your new setting becomes the new default setting.

For example if you change the Sleep timer setting from 30 minutes to 45 minutes, 45 minutes becomes the new default Sleep timer setting until you change it again.

4. When the Sleep timer counts down to “00,” the power shuts off automatically.

NAP Timer (Buzzer Alarm Only)

The Nap timer function will wake you to the buzzer alarm after a nap of up to 99 minutes without the need to change your regular Alarm 1 or Alarm 2 settings.

1. If the system is playing, shut the power ‘Off.’
2. Press the NAP button on the top panel. The display will briefly show “n:30” and the NAP indicator appears.



After 30 minutes the crescendo buzzer alarm will turn on to wake you up.

3. To change the amount of naptime depress and hold the NAP button and press the ◀◀ or ▶▶ buttons to decrease or increase the amount of naptime from two minutes to 99 minutes.

Note: When you change the Nap timer from the original 30-minute default setting your new setting becomes the new default setting.

For example if you change the Nap timer setting from 30 minutes to 45 minutes, 45 minutes becomes the new default Nap timer setting until you change it again.

DIMMER Control

The display dimmer control was set to the HI (High) position at the factory.


If you find the display to be too bright for sleeping, slide the DIMMER switch to the LO (Low) position.

Changing The Lithium Battery

Like all batteries, eventually the built-in lithium battery will need to be replaced. A number of factors, such as the length of time between the date the radio was manufactured and the date you plugged it in for the first time, determine the amount of time before replacement.

During this initial storage period, the lithium battery is supplying power to the SmartSet® computer memory. Once you plug the radio in, your household outlet supplies the power, and the battery is not being used.

A fresh lithium battery can supply power to the SmartSet® computer for at least three years even if it is never connected to an AC power supply. If your radio was connected to your AC supply within a few months after it was manufactured, and you experience only the normal, nuisance-type, short duration power interruptions, your battery may last for up to five years or even longer.

When the battery power drops below a certain level, the  **LOW** indicator will flash. When you see this indicator, you should change the battery as soon as it is convenient for you to do so. To change the battery, proceed as follows:

1. Purchase a replacement 3V lithium battery wherever batteries are sold. The battery type is CR2430 or equivalent.
2. Remove the battery from its package so it is ready to install.


IMPORTANT: Leave the radio power cord connected to your AC outlet. This will provide power to the SmartSet® computer memory while the original lithium battery is removed.


3. Turn the radio upside down and use a small screwdriver to remove the two screws securing the battery holder to the cabinet.

BE CAREFUL NOT TO LOSE THESE SMALL SCREWS!


4. Remove the original battery from the holder and insert the new battery into the holder the same way, observing the positive (+) direction.

Slide the holder with the new battery back into the slot in the cabinet.



5. Replace the screws that secure the battery holder in the cabinet.
6. Turn the radio right side up and confirm that the  **LOW** indicator is no longer flashing or 'Off' if you also have installed a 9V battery.
7. Save these instructions. You'll have to do this again five to eight years from now!

Resetting The Clock After A Total Memory Loss

If you do not change the built-in lithium battery within a reasonable period of time after you see the flashing  **LOW** warning indicator, the lithium battery may become exhausted and will no longer be able to supply back up power to the SmartSet® internal computer.

If the unit is disconnected from the AC outlet after the battery is exhausted, or if a power interruption occurs, the SmartSet® memory will be lost and the clock will need to be reset when the power is restored. Be sure to install a fresh lithium battery before you reset the clock, otherwise the clock will need to be reset each time the power is interrupted.

If the lithium battery is exhausted and you experience an interruption in the AC power supply, the clock will reset itself to its initial default setting when the power is restored.

The initial default setting is "AM 12:00, Saturday, January 1st (1 01), 2005".

If you notice that the time on your SmartSet® CD Alarm Clock Radio is completely incorrect, and the day indicator is also wrong, press the MONTH/DATE button to see the date. If the date display is incorrect, you probably experienced a total memory loss. To reset the clock after a total memory loss, proceed as follows:

1. Follow the instructions on pages 48-51 and install a new CR2430 lithium battery in the battery compartment.
2. Connect the radio to your AC outlet and let the clock set itself.
3. Depress the MONTH/DATE and TIME buttons together. The display will change from 'time' to 'year.'
4. While holding the MONTH/DATE and TIME buttons, press the ►► button to set the display to the correct year if necessary, then release the buttons.
5. Depress the MONTH/DATE button. The display will change from 'time' to 'month/date' (mm/dd).
6. While holding the MONTH/DATE button, press the ►► button to set the display to the correct month and date. The Day indicator will change automatically as you adjust the month/date settings. When the correct month and date appear on the display, release the buttons.
7. Depress the TIME button and the ►► button to set the display to the correct time. Be sure to confirm that you have set the time correctly to 'AM' or 'PM' by observing the AM indicator.

8. After you set the time, reconfirm that the Day, and Month/Date displays are still correct. Make final adjustments if necessary.

The SmartSet® clock memory is now reset and the new lithium battery will maintain it for the next five to eight years, depending on the number and duration of the power outages you experience.

Important Note

After resetting the clock, don't forget to reset your wake up times, and alarm mode settings, and sleep timer settings as well.

CARE AND MAINTENANCE

Lithium Battery Precautions

- Dispose of the old battery properly. Do not leave it lying around where a child or pet could play with, or swallow it. If the battery is swallowed, contact a physician immediately.
- Battery may explode if mistreated. Do not attempt to recharge it or disassemble it. Do not dispose of the old battery in a fire.

CD Care

- To remove a disc from its storage case, press down on the center of the case and lift the disc out, holding it carefully by the edges.



- Fingerprints and dust should be carefully wiped off the disc's recorded surface with a soft cloth. Unlike conventional records, compact discs have no grooves to collect dust and microscopic debris, so gently wiping with a soft cloth should remove most particles. Wipe in a straight line from the inside to the outside of the disc. Small dust particles and light stains will have absolutely no effect on reproduction quality.



- Clean the disc periodically with a soft, lint-free, dry cloth.
Never use detergents or abrasive cleaners to clean the disc.
If necessary, use a CD cleaning kit.
- Never write on or affix labels to the surface of compact discs.

Care Of The Cabinet

If the cabinet becomes dusty wipe it with a soft dry dust cloth.
Do not use any wax, polish sprays, or abrasive cleaners on the cabinet.

Caution

Never allow any water or other liquids to get inside the unit while cleaning.

One (1) Year Limited Warranty

Brookstone warrants this product against defects in materials and/or workmanship under normal use for a period of ONE (1) YEAR from the date of purchase by the original purchaser ("Warranty Period"). If a defect arises and a valid claim is received within the Warranty Period, at its option, Brookstone will either 1) repair the defect at no charge, using new or refurbished replacement parts, or 2) replace the product with a new product that is at least functionally equivalent to the original product, or 3) provide a store credit in the amount of the purchase price of the original product. A replacement product or part, including a user-installable part installed in accordance with instructions provided by Brookstone, assumes the remaining warranty of the original product. When a product or part is exchanged, any replacement item becomes your property and the replaced item becomes Brookstone's property. When a store credit is given, the original product must be returned to Brookstone and becomes Brookstone's property.

Obtaining Service: To obtain warranty service, call Brookstone Limited Warranty Service at 1-800-292-9819. Please be prepared to describe the product that needs service and the nature of the problem. A purchase receipt is required. All repairs and replacements must be authorized in advance. Service options, parts availability and response times will vary. You are responsible for delivery and the cost of delivery of the product or any parts to the authorized service center for replacement, per our instructions.

Limits and Exclusions: Coverage under this Limited Warranty is limited to the United States of America, including the District of Columbia and the U.S. Territories of Guam, Puerto Rico, and U.S. Virgin Islands.

This Limited Warranty applies only to products manufactured for Brookstone that can be identified by the "Brookstone" trademark, trade name, or logo affixed to them or their packaging. The Limited Warranty does not apply to any non-Brookstone products. Manufacturers or suppliers other than Brookstone may provide their own warranties to the purchaser, but Brookstone, in so far as permitted by law, provides these products "as is."

This warranty does not apply to: a) damage caused by failure to follow instructions relating to product's use or the installation of components; b) damage caused by accident, abuse, misuse, fire, floods, earthquake or other external causes; c) damage caused by service performed by anyone who is not a representative of Brookstone; d) accessories used in conjunction with a covered product; e) a product or part that has been modified to alter functionality or capability; f) items intended to be periodically replaced by the purchaser during the normal life of the product including, without limitation, batteries or light bulbs; or g) any and all pre-existing conditions that occur prior to the effective date of this Limited Warranty relating to any product sold "as is" including, without limitation, floor demonstration models and refurbished items.

BROOKSTONE SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT, OR ARISING OUT OF ANY BREACH OF THIS WARRANTY. TO THE EXTENT PERMITTED BY APPLICABLE LAW, BROOKSTONE DISCLAIMS ANY AND ALL STATUTORY OR IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND WARRANTIES AGAINST HIDDEN OR LATENT DEFECTS. IF BROOKSTONE CANNOT LAWFULLY DISCLAIM STATUTORY OR IMPLIED WARRANTIES, THEN TO THE EXTENT PERMITTED BY LAW, ALL SUCH WARRANTIES SHALL BE LIMITED IN DURATION TO THE DURATION OF THIS EXPRESS WARRANTY.

Some states disallow the exclusion or limitation of incidental or consequential damages or how long an implied warranty lasts, so the above exclusions or limitations may not apply to you. This warranty gives you specific legal rights and you may also have other rights, which vary from state to state.

Brookstone®

Merrimack, New Hampshire 03054

Customer Service 800-846-3000

www.brookstone.com

467522