

Tiny Touch™ Tablet



© 2012 VTech
Printed in China
91-002758-009

INTRODUCTION

Thank you for purchasing the **VTech® Tiny Touch™ Tablet** learning toy!

Your little one will have fun playing with the **VTech® Tiny Touch™ Tablet**! This beginner tablet has nine brightly colored light-up activity buttons that introduce a variety of curriculum to your baby including letters, numbers, animals, days of the week, and more! For added fun, your baby can roll the ball to activate fun light patterns that they'll love to follow. Designed especially for little hands, your baby will want to take this tablet everywhere!



INCLUDED IN THIS PACKAGE

- One **VTech® Tiny Touch™ Tablet**
- One user's manual

WARNING:

All packing materials, such as tape, plastic sheets, packaging locks and tags are not part of this toy, and should be discarded for your child's safety.

ATTENTION:

Pour la sécurité de votre enfant, débarrassez-vous de tous les produits d'emballage tels que rubans adhésifs, feuilles de plastique, attaches et étiquettes. Ils ne font pas partie du jouet.

NOTE:

Please keep this user's manual as it contains important information.

GETTING STARTED

BATTERY INSTALLATION

1. Make sure the unit is turned **OFF**.
2. Locate the battery cover on the back of the unit. Use a screwdriver to loosen the screw.
3. Install 2 new 'AAA' (AM-4/LR03) batteries following the diagram inside the battery box. (The use of new alkaline batteries is recommended for maximum performance.)






4. Replace the battery cover and tighten the screw to secure the battery cover.


BATTERY NOTICE

- Use new alkaline batteries for maximum performance.
- Use only batteries of the same or equivalent type as recommended.
- Do not mix different types of batteries: alkaline, standard (carbon-zinc) or rechargeable (Ni-Cd, Ni-MH), or new and used batteries.
- Do not use damaged batteries.
- Insert batteries with the correct polarity.
- Do not short-circuit the battery terminals.
- Remove exhausted batteries from the toy.
- Remove batteries during long periods of non-use.
- Do not dispose of batteries in fire.
- Do not charge non-rechargeable batteries.
- Remove rechargeable batteries from the toy before charging (if removable).
- Rechargeable batteries are only to be charged under adult supervision.

PRODUCT FEATURES

1. ON/OFF/VOLUME CONTROL SWITCH

To turn the unit **ON**, slide the **ON/OFF/VOLUME CONTROL SWITCH** to the **LOW VOLUME** () or **HIGH VOLUME** () position. To turn the unit **OFF**, slide the **ON/OFF/VOLUME CONTROL SWITCH** to the **OFF** () position.




2. AUTOMATIC SHUT-OFF


To preserve battery life, the **VTech® Tiny Touch™ Tablet** will automatically power-down after approximately 60 seconds without input. The unit can be turned on again by pressing any button. Rolling the roller ball will not turn the unit back on.

ACTIVITIES


1. Slide the **on/off/volume control switch** to turn the unit on. You will hear a sing-along song and a playful phrase. The lights will flash with the sound.
2. Press the **animal buttons** to learn animal names, colors and sounds. The lights will flash with the sound.



3. Press the **camera button** to hear fun role-play phrases and sounds. The lights will flash with the sound.




4. Press the **sound effect button** to hear a variety of fun sounds and short tunes. The lights will flash with the sound.



5. Press the **music button** to hear a variety of melodies and a sing-along song. The lights will flash with the sound.




6. Press the **calendar button** to learn numbers and days of the week. The lights will flash with the sound.



7. Press the **ABC button** to learn letters and hear the Alphabet Song. The lights will flash with the sound.



8. Press the **mail button** to hear fun role-play phrases and sounds. The lights will flash with the sound.



9. Roll the **roller ball** to hear fun sounds and to control the light pattern on the tablet.



MELODY LIST

1. One, Two, Buckle My Shoe
2. Did You Ever See a Lassie?
3. Oh! Susanna
4. Polly Put the Kettle On
5. Humpty Dumpty
6. Row, Row, Row Your Boat
7. Blow the Man Down
8. Hot Cross Buns
9. Little Boy Blue
10. London Bridge

SONG LYRICS

SONG 1

Hello friend, come play with me,
There's lots to learn you will see!

SONG 2 (To the tune of "Clementine")

Sunday, Monday,

Tuesday, Wednesday,

Thursday, Friday,

Saturday, seven days in a week!

SONG 3

A B C D E F G,

H I J K L M N O P,

Q R S T U V,

W X Y and Z.

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat source.
3. Remove the batteries when the unit will not be in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

TROUBLESHOOTING

If for some reason the program/activity stops working or malfunctions, please follow these steps:

1. Please turn the unit **OFF**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit **ON**. The unit should now be ready to play again.

5. If the product still does not work, replace with a new set of batteries.

If the problem persists, please call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada, and a service representative will be happy to help you.

For information on this product's warranty, please call **VTech®** at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada.

IMPORTANT NOTE:

Creating and developing **Infant Learning** products is accompanied by a responsibility that we at **VTech®** take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada, with any problems and/or suggestions that you might have. A service representative will be happy to help you.

CC Information:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment operates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS:
(1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND
(2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRABLE OPERATION.

THIS CLASS B DIGITAL APPARATUS COMPLIES WITH CANADIAN ICES-003.
CET APPAREIL NUMÉRIQUE DE LA CLASSE B EST CONFORME À LA NORME NMB-003 DU CANADA.

