
USER'S MANUAL





Contents

	Product Safety Instructions
INST	ALLATION
	Package Contents 6 Front View of the LCD TV 6 Side View of the LCD TV 7 Rear View of the LCD TV 9 Remote Controls 10 Installation 11
OSD	Functions
	PICTURE PARAMETERS: Brightness / Contrast / Saturation / Hue / Color Temp / Sharpness / Aspect Ratio / Backlight / Reset
	System Info / Factory Reset

Explanations of required symbols :

SYMBOL	SYMBOL DEFINITION
SA 1965	DANGEROUS VOLTAGE: The lightning flash with arrowhead symbol, inside an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electrical shock to persons.
SA 1966	INSTRUCTIONS: The exclamation point inside an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

PRODUCT SAFETY INSTRUCTIONS

Follow and obey all warnings and instructions marked on the LCD TV. For your safety, please read all the safety and operating instructions before you operate the LCD TV. Keep this user's manual for future reference.

Overloading

Do not overload wall outlets, extension cords, or power strips. This can result in fire or electronic shock.

Power Cord Protection

Power supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them. Periodically inspect the cords and each end of the cords for damage. The LCD TV shall be installed near a wall socket outlet and the plug on power cord shall be readily accessible.

Ventilation

Slots and openings on the cabinet are provided for ventilation purposes. To ensure reliable operation of the LCD TV and to protect it from overheating, these openings must not be blocked or covered.

- Do not block the openings by placing the LCD TV on a bed, sofa, rug or other similar surface.
- Do not place the LCD TV in a built-in installation such as a bookcase or rack unless proper ventilation is provided and the manufacturer's instruction have been adhered to.

Other Notices

- Avoid exposing the LCD TV to direct sunlight or high temperatures.
- Avoid exposing the LCD TV to moisture or high humidity.
- Do not attempt repairs yourself. Your warranty does not cover repairs or attempted repairs by anyone not authorized by Westinghouse Digital.
- If your LCD TV will not be used for a long period of time, unplug the LCD TV and remove the batteries from the remote control.

Precautions

- Avoid touching the screen. Skin oils are difficult to remove.
- Never remove the rear cover. Your LCD TV contains high-voltage parts. You may be seriously injured if you touch them.
- Avoid exposing your LCD TV to direct sunlight or another heat source. Orient your LCD TV away from direct sunlight to reduce glare.
- Always handle your LCD display with care when moving it.
- Place your LCD TV in a well-ventilated area; don't place the LCD TV in airtight compartments. Do not place anything on your LCD TV that prevents heat dissipation.
- Ensure that the area around the LCD TV is clean and free of moisture.
- Do not place heavy objects on the LCD TV, audio/video cables, or power cord.
- If the LCD TV emits smoke, abnormal noise, or a strange odor, immediately turn it
 off and contact the Westinghouse Service Center.
- WARNING To Reduce The Risk Of Fire Or Electric Shock, Do Not Expose
 The LCD TV To Rain Or Moisture! The LCD TV shall not be exposed to dripping or
 splashing and objects filled with liquids, such as vases, shall not be placed on the
 TV.

Antenna Installation Safety

Outdoor Antenna Grounding

If an outside antenna or cable system is connected to the LCD TV, be sure the antenna or cable system is grounded to prevent voltage surges and built-up static charges. Article 810 of the National Electrical Code, ANS/NFPA 70, provides information on proper grounding of the mast and supporting structure, grounding of the lead-in wire to an antenna discharge unit, connection to grounding electrodes, and requirements for the grounding electrode.

Lightning

For added protection for the LCD TV during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the antenna or cable system. This will prevent damage to the LCD TV due to lightning and power-line surges. Do not disconnect the antenna or the power cord during a heavy storm – lightning may strike while you are holding the cable cord, causing serious injury. Turn off your LCD TV and wait for the weather to improve.

Power Lines

An outside antenna system should not be located in the vicinity of overhead power lines or other electric light or power circuits. When installing an outside antenna system, extreme care should be taken to keep from touching such power lines or circuits.

- 1) Read these instructions.
- Keep these instructions.
- Heed all warnings.
- 4) Follow all instructions.
- Do not use the LCD TV near water.
- 6) Clean only with a dry cloth.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- 9) Do not attempt to bypass the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding-type plug has two blades and a third grounding prong. If the provided plug does not fit into your wall outlet, consult an electrician for replacement of the obsolete outlet.
- Protect the power cord from being walked on or pinched particularly at the ends of the cord.
- 11) Only use attachments/accessories specified by the manufacturer.
- 12) Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the LCD TV. When a cart is used, use caution when moving the cart to avoid injury or damage.
- Unplug the LCD TV during lightning storms or when it is not being used for a long period of time.
- 14) Refer all servicing to qualified service personnel. Servicing is required when the LCD TV has been damaged in any way, such as the power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the LCD TV, it has been exposed to rain or moisture, it does not operate normally, or the TV has been dropped.

Safety Guidelines

WARNING: This device must be operated with the original power supply, part number DPS-210 EP 2 C.

CAUTION: The power supply outlet should be located near the LCD TV and should be easily accessible. Always use the appropriate AC cord that is certified for your specific country. Some examples are listed below:

USA.....UL Switzerland SEV
Canada.....CSA Britain BASE/BS

Germany......VDE Japan Electric Appliance Control Act

IMPORTANT NOTICE CONCERNING POWER CORD SELECTION

The specific power cord for this LCD TV is enclosed and has been selected according to the country of destination and must be used to prevent electric shock. Use the following guidelines if it is necessary to replace the original cord set, or if the cord set is not enclosed. The female receptacle of the cord set must meet IEC-60320 requirements and should look like Figure A1 below:



For the United States and Canada

In the United States and Canada the male plug is a NEMA5-15 style (Figure A2), UL Listed, and CSA Labeled. For LCD TVs that are placed on a desk or table, type SVT or SJT cord sets may be used. For LCD TVs placed directly on the floor, only SJT type cord sets may be used. The cord set must be selected according to the current rating for the LCD TV. Please consult the table below for the selection criteria for power cords used in the United States and Canada.

Cord Type	Size of Conductors in Cord	Maximum Current Rating of Unit
SJT	18 AWG	10 Amps
	16 AWG	12 Amps
	14 AWG	12 Amps
SVT	18 AWG	10 Amps
	17 AWG	12 Amps

FCC Compliance Statement

This equipment has been tested and complies with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and may cause harmful interference to radio communications if not installed and used in accordance with the instructions. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the LCD TV and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the Westinghouse Service Center or an experienced radio/TV technician for assistance.

FCC Warning

To assure continued FCC compliance, the user must use a grounded power supply cord and the provided shielded video interface cable with bonded ferrite cores. If a BNC cable used, use only a shielded BNC (5) cable. Also, any unauthorized changes or modifications not expressly approved by Westinghouse Digital will void the user's authority to operate this device.

Cleaning the LCD TV

- MAKE SURE THE LCD TV IS TURNED OFF
- NEVER SPRAY OR POUR ANY LIQUID DIRECTLY ONTO THE SCREEN OR CASE

To clean the screen:

- Wipe the screen with a clean, soft, lint-free cloth. This removes dust and other particles.
- If it still is not clean, apply a small amount of non-ammonia, non-alcohol based glass cleaner onto a clean, soft, lint-free cloth, and wipe the screen.

To clean the case:

- Use a soft, dry cloth.
- If it still is not clean, apply a small amount of non-ammonia, non-alcohol based, mild nonabrasive detergent onto a clean, soft, lint-free cloth, then wipe the surface.

Disclaimer

Westinghouse Digital does not recommend the use of any ammonia or alcohol-based cleaners on the LCD TV screen or case. Some chemical cleaners have been reported to damage the screen and/or LCD TV case. Westinghouse Digital will not be liable for damage resulting from the use of any ammonia or alcohol-based cleaners.

INSTALLATION

Package Contents


Your product package includes:

- A 27" or 32" Westinghouse LCD TV
- · Remote Control (with batteries)
- Power Cord
- Quick Connect Guide
- User's Manual
- · Component Video Cable (Green, Blue, Red)
- Audio Cable (Red, White)




Front View of the LCD TV

Use the buttons on the right side of the LCD TV or on the remote control to display the On Screen Display (OSD). The OSD controls are defined in "OSD Functions" on page 14.



Side View of the LCD TV

1-41	1. Menu	Turn OSD Menu ON/OFF
2 —	2. Volume + / -	Increase/Decrease sound volume or adjust a highlighted control while in the OSD Menu.
3 —	3. Channel + / -	Channel up/down when input is TV or highlight a control while in the OSD Menu.
4 — [4. Input	Select Active Video Input or choose a selection while in the OSD MENU.
	5. Power Button	Power ON/OFF




A/B. AV2 Audio Input (Left / Right)

Connect an external audio source to these jacks (Audio (R/L)).

C. AV2 Video Input

Connect an external video device such as a VCR, DVD or video game system.

D. Headphone Jack.



1. S-Video Input

Connect to an external video device such as a digital cable/satellite receiver, VCR, DVD or video game system.

2. AV1 Video Input

Connect the Composite Video to an external video device such as VCR, DVD and video game system.

3. AV1 & S-Video Audio Input (Right / Left)

Connect an external audio source to this jack; (Audio (R/L). This connection supports either S-Video or AV input.

4. Audio Output (Right / Left)

Connect this output to an external audio receiver.

5. ANT (RF-input)

Connect the LCD TV to an antenna or cable service

6. VGA Audio IN

Using the cable provided, connect to the Audio out (Green) from a computer.

7. VGA

Using a 15-pin VGA cable, connect to a computer or other device with a VGA output.

8. DVI Audio Input (Right / Left)

Connect an external audio to this jack.

9. DVI

Using a 20-pin DVI cable, connect to a computer or other device with a DVI output.

10. YPbPr1 Input

Connect an external video devices with component output to these jacks.

11. YPbPr1 Audio 1 Input (Left / Right)

Connect an external audio source to this jack.

12. YPbPr2 Input


Connect an external video device with component output to these jacks.

13. YPbPr2 Audio 2 Input (Left / Right)

Connect an external audio source to this jack.


14. AC IN (Power)

Connect the power cord from AC IN to a power source.




Rear View of the LCD TV

27 inch LCD TV



32 inch LCD TV



Remote Control

The Remote Control will transmit to the LCD TV up to 23 feet away.

1. POWER:

Switch the power On/Off

2. INPUT

Select input source

3. CHANNEL NUMBER KEYS

Select specific channels

4. LAST CH

Switch to previous channel

5. MENU/EXIT

Turn OSD Menu On/Off or quit the TV channel scanning

6. SCALING

Select Video Display format "STANDARD" or "FILL" or "ZOOM"

7. ▼/▲/◀/▶

OSD MENU control

8. Enter

Execute a command

9. MUTE

Turn the Sound On/Off

10. INFO.

Display the source and channel information

11. PIP

Display Sub picture On/Off

12. FREEZE

Freeze main screen

13. VOL - / +

Volume Up/Down adjustment

14.CH ▼ / ▲

TV Channel Up/Down adjustment

15. YPbPr

Select YPbPr1 / YPbPr2 source input

16. PC

Select VGA / DVI source input

17. TV


Select TV source input

18. S-Video

Select S-Video source input

19. AV

Select AV1 / AV2 source input



Installation

1. Insert Remote Control Batteries

- Remove the battery cover.
- Insert the batteries corresponding to the (+) and (-) marks on the battery compartment.



Re-attach the battery cover.

CAUTION:

- Only use AAA batteries.
- Do not mix new and old batteries. This may result in cracking or leakage, which may pose a fire
 risk or lead to personal injury.
- Insert batteries according to (+) and (-) markings. Inserting the batteries incorrectly may result
 in cracking or leakage, which may pose a fire risk or lead to personal injury.
- Dispose of used batteries in accordance with local laws and regulations.
- · Keep batteries away from children and pets.
- When the remote control will not to be used for an extended period, remove the batteries.

2. Connect audio and video cables to a PC

Connect one or all of the following into the back of the LCD TV

IMPORTANT: Before beginning, make sure all devices are turned off.


VGA CONNECTION: Connect an analog VGA cable from your PC VGA OUT port to the LCD TV VGA IN port.

DVI CONNECTION: Connect a Digital DVI cable from your PC or DVD DVI OUT port to the LCD TV DVI-HDCP port.

AUDIO CONNECTION: Connect a stereo mini cable from the PC's AUDIO OUT port to the AUDIO IN port on the LCD TV.

3. Connect AV, Component, S-Video, Antenna/Cable to Video Devices

Connect Video/Audio cables from compatible devices to the back panel of the LCD TV.



4. Connect power cables

Connect the power cord to the LCD TV then to a properly grounded AC outlet.

27 inch LCD TV





5. Turn Power On

Press the Power ON button on the right side of the LCD TV, or press the Power ON (Red) button on the remote control.



Select input source for the LCD TV using the OSD menu or remote control

7. If connecting to Antenna, Cable or other RF source on TV Inputs: See page 19 to auto scan and edit available channels.

8. If connecting to a PC (VGA/DVI):

For the best picture quality, set the timing mode of you computer to 1280 x 720 at 75Hz (for 27 inch LCD TV) or 1360 x 768 at 60Hz (for 32 inch LCD TV). Refer to the graphic card's user guide of you computer to set this timing mode.

OSD Function


All the OSD function settings are controlled either by the remote control or using the control keys on the right side of LCD TV.

To display the OSD main menu, press the Menu button on the right side of front control keys of the LCD TV or the MENU key on the remote control. Use ⁴ / ▶ arrow keys to highlight the desired OSD sub-menu.




Main Menu

To select a sub-menu, press ▲/▼ on the right side of the LCD TV or the ▲/▼ key on the remote control.




PICTURE PARAMETERS:



Function Name	Function
Brightness	Brightness adjustment
Contrast	Contrast adjustment
Saturation	Saturation adjustment
Hue	Hue adjustment
Color Temp	Color temperature adjustment (Color 1, Color 2, Color 3)
Sharpness	Sharpness adjustment (Sharpness cannot be adjusted in PC mode)
Aspect Ratio	Set display to "STANDARD" / "FILL" / "ZOOM"
Backlight	Backlight adjustment
Reset	Reset video settings


PC PARAMETERS:



Function Name	Function
Auto Adjust	Automatically adjust the horizontal phase of the image
Clock	Clock adjustment
Phase	Phase adjustment
Position	Adjust the horizontal and vertical position of the image


NOTE: The GRAPHIC menu is only available when VGA source is selected.

AUDIO SETTINGS:



Function Name	Function
Volume	Volume adjustment
Bass	Bass adjustment
Treble	Treble adjustment
Balance	Balance adjustment
MTS	MTS Selection NOTE: This function depends on the type of broadcast being received.
Mute	Select Audio OFF or ON
Speaker	Select internal or external speaker
Reset	Reset audio settings

PICTURE-IN-PICTURE:



Function Name	Function
Display Mode	OFF> PIP> PBP> POP
Main Source	Select main screen sources TV> AV1> AV2> S Video> YPbPr1> YPbPr2> VGA> DVI
PIP Source	Select sub screen sources Please see PIP/PBP/POP specification in Table 1
Swap	Swap main screen and sub-screen source
PIP Position	Sub-screen display horizontal/vertical position adjustment
PIP Size	Sub-screen display size adjustment (Small>Medium> Large)
Audio From	Select main screen or sub-screen audio sources

Table 1:

SUB Main	VGA	DVI	AV1	AV2	S Video	YPbPr1	YPbPr2	TV
VGA	Х	0	0	0	0	Х	Х	0
DVI	0	Х	0	0	0	0	0	0
AV1	0	0	Х	Х	Х	0	0	Х
AV2	0	0	Х	Х	Х	0	0	Х
S Video	0	0	Х	Х	Х	0	0	Х
YPbPr1	Х	0	0	0	0	Х	Х	0
YPbPr2	Х	0	0	0	0	Х	Х	0
TV	0	0	Х	Х	Х	0	0	Х

CHANNEL SETTINGS:




Function Name	Function					
TV / CATV	Select TV Source Type (ANTENNA => Cable STD => Cable HRC => Cable IRC)					
Auto Scan	Automatically detect available TV channels					
Channel EDIT	Add / Delete the selected TV channel					
Close Caption	Turn the Close Caption OFF or CC1, CC2, CC3, CC4, TEXT1, TEXT2, TEXT3, TEXT4					


PARENTAL CONTROLS:



Function Name	Function
Lock Menu	Turn parental control OFF or ON
MPAA Rating	See page 20
TV PG Rating	See page 20
Password EDIT	Change Password (see page 20)



GENERAL SETTINGS:



Function Name	Function
Menu Position	OSD horizontal/vertical position adjustment
Menu Timeout	Set the time to turn off the OSD automatically
Language	OSD language selection
Sleep Timer	Set sleep timer to turn off the power automatically
Transparency	Set OSD transparency level
DPMS	Select DPMS On/Off
System Info	Display Input source, type and signal
Factory Reset	Restore factory default settings

32 inch LCD TV Specifications

Model Name		LTV-32w1		
Panel	Туре	TFT (Thin Film Transistor), Activ I stripe		
	Color	Anti-reflective coating + Anti-glare coating		
Viewing Angles		170° (H) / 170° (V)		
Input Signal	Video/Audio	VGA Analog * 1 (75 ohms, 0.7 Vp-p)/Mini-Stereo *1		
		H/V separated (TTL) for PC		
		DVI-D * 1 (HDCP support) / RGA (L/R) * 1		
		fh: 30-80 kHz, fv: 50-75 Hz		
		TV system antenna / NTSC *1 in US and TW		
		Component Video * 2 / RCA (L/R) Stereo * 2		
		Composite * 1 / S-Video * 1 / RCA (L/R) stereo * 1		
		Composite * 1 / RCA (L/R) Stereo * 1, Headphone Mini-Stereo *1(side I/P)		
Output Signal		RCA (L/R) Stereo * 1		
HDTV Compatibility		480i, 480P, 720P, 1080i		
PC Compatible	Recommended	1360 x 768 @ 60Hz		
	Supported	1280 x 1024 @ 60, 75Hz	800 x 600 @ 60, 75 Hz	
		1024 x 768 @ 70, 75 Hz	720 x 400 @ 70 Hz	
		848 x 480 @ 60Hz	640 x 480 @ 60, 75 Hz	
		832 x 624 @ 75Hz (MAC)		
Speaker Output		9w (x 2 Channels)		
Power	Voltage	90-240 VAC, 50/60 Hz (auto switch), 1	.8A, universal.	
Temperature (Note A)	Operating	0 to + 35° C (Hum.<90%)	Relative Humidity (NRH)	
	Storage	-20 to +60 °C (Hum.< 35 %)	90	
Humidity (Relative). (Note A)	Operating	20 to 90% non-condensing.(Ta< 35%)	м .	
	Storage	10 to 90% non-condensing. (Note A)	00 Operating Range	
		erature should be 39°C Max. (Ta> 40°C) inperature and relative humidity range is ide		
Altitude	Operating	0 to 3,000 m		
	Storage	0 to 12,000m	-81 -31 (31 46 46 Temperatura (*C)	
Dimensions	Physical	797mm (W) x 641mm (H) x 112.7mm (
Weight	Net / Gross	18.0kg / 22.0kg		
Regulations		UL/C-UL, FCC-B		
Power saving	On	<180w (Blue LED)		
Modes	Active Off	<3w		

Preset Timing Mode (Pre-adjusted to reduce blanking: 1360 x 768 at 60Hz)

Warning: Do not set the graphics card in your computer to exceed these refresh rates; doing so may result in permanent damage to the LCD TV.

Note: Product Specifications are subject to change without notice.

27 inch LCD TV Specifications

Model Name		LTV-27w2		
Panel	Туре	27" (26.97" viewable diagonal area), Matrix WXGA LCD, 1280 x 720 vertical		
	Color	Anti-reflective coating + Anti-glare coati	ng	
Viewing Angles		170° (H) / 170° (V)		
Input Signal	Video/Audio	VGA Analog * 1 (75 ohms, 0.7 Vp-p)/Mini-Stereo *1		
		H/V separated (TTL) for PC		
		DVI-D * 1 (HDCP support) / RCA (L/R) * 1		
		fh: 30-80 kHz, fv: 50-75 Hz		
		TV system antenna / NTSC*1 in US and TW		
		Component Video * 2 / RCA (L/R) Stereo * 2		
		Composite * 1 / S-Video * 1 / RCA (L/R) stereo * 1		
		Composite * 1 / RCA (L/R) Stereo * 1, Headphone Mini-Stereo *1(side I/P)		
Output Signal		RCA (L/R) Stereo * 1		
HDTV Compatibility		480i, 480P, 720P, 1080i		
PC Compatible	Recommended	1 1280 x 720 @ 75Hz		
	Supported	1280 x 1024 @ 60, 75Hz	800 x 600 @ 60, 75Hz	
		1280 x 768 @ 60 Hz	720 x 400 @ 70 Hz	
		1024 x 768 @ 60, 75 Hz 832 x 624 @ 75Hz	640 x 480 @ 60, 75Hz	
Speaker Output		9w (x 2 Channels)		
Power	Voltage	90-240 VAC, 50/60 Hz (auto switch), 1.	6A, universal.	
Temperature (Note A)	Operating	0 to + 35° C (Hum.<90%)	Roldins Humidity (1,704)	
	Storage	-20 to +60 °C (Hum.< 35 %)	100	
Humidity (Relative). (Note A)	Operating	20 to 90% non-condensing.(Ta< 35%)		
	Storage	10 to 90% non-condensing. (Note A)		
	Wet-bulb temp	erature should be 39 °C Max. (Ta> 40°C)	Operating Range	
	Note A: The temperature and relative humidity range is shown in right side			
Altitude	Operating	0 to 3,000 m	g Storage Range	
	Storage	0 to 12,000m	-49 -31 E 31 45 60 H	
Dimensions	Physical	676.84mm (W) x 556.76mm (H) x 186.2	2mm (D)	
Weight	Net / Gross	13.0kg / 16.0kg		
Regulations		UL/C-UL, FCC-B		
Power saving	On	<150w (Blue LED)		
Modes	Active Off	<3w		

Warning: Do not set the graphics card in your computer to exceed these refresh rates; doing so may result in permanent damage to the LCD TV.

Note: Product Specifications are subject to change without notice.

Troubleshooting

No Power

- Make sure power button is ON (Blue LED).
- Make sure AC power cord is securely connected to the AC socket.
- Plug another electrical device (such as a radio) to the power outlet to verify that the outlet is supplying the proper voltage.

Parental Control Password is "LOST"

 In the unlikely occurrence, select "PASSWORD EDIT" and enter "0000" to reset the password.

AUDIO Interconnection Issues

Remember that S-Video and Composite (AV1) share the same audio source.

Power is ON but No Screen Image

- Make sure the video cable connected to the LCD TV is tightly secured to the video output port on the back of the computer. If the other end of the video cable is not attached properly to the LCD TV, secure it tightly.
- Adjust brightness and contrast.
- If you are using a Macintosh computer older than G3, you need a Macintosh adapter.
- Check Source settings.

Wrong or Abnormal Colors

- If any colors (red, green, or blue) are missing, check the video cable to make sure it is connected securely. Loose or broken pins in the cable connector could cause an improper connection.
- Connect the LCD TV to another computer.

Remote Control Buttons Do Not Work

Press only one button at a time.

Snow Appears on Screen

- Check your antenna connection.
- Check the TV / CATV selection.

No Sound

- Check the audio connection.
- Press MUTE on the remote control, so that MUTE disappears from the screen.
- Check the audio settings. The LCD TV audio may be set to SAP or minimum.
- Press the Volume + (Up) key on the remote control.
- Make sure that headphones are not connected to the Headphone Jack on the LCD TV.
- Make sure the speaker setting is set to "internal".

Remote Control Does Not Work

- Make sure batteries are inserted correctly.
- · Replace batteries with new ones if necessary.

Remote Control Code Not Found in a "Universal" Remote

· Purchase a separate "learning" remote control.

Image Quality Issues

 For the best TV image quality, "Standard Definition" TV should be viewed in 4:3 format.

How Can I Find More Help?

- Log on to: www.westinghousedigital.com
- Contact Westinghouse Customer Service at (866) 287-5555 or write us at service@westinghousedigital.com

