

LEXON[®]

**TITANIUM CLOCK RADIO
LA 83**

**MODE D'EMPLOI
OPERATION MANUAL
GEBRAUCHSANWEISUNG
INSTRUCCIONES
ISTRUZIONI
ИНСТРУКЦИЯ ПО ЭКСПЛУАТАЦИИ
取扱説明書
操作指南
사용 설명서**



INSTRUKSI MANUAL

ENGLISH

A. Clock Mode

1. When connect it with the adaptor, the time "0:00" will be displayed on the screen.
2. Time Adjusting: After 3 seconds pressing button "CLOCK", the LED digital display will showed "24:00" and flashing. Then you can press \wedge change the time display system in 12 time system, after chosen one system then press the button CLOCK, the hour digital display will be flashing. At this time press button \wedge to add hour and press \vee to reduce hour. Then press button "CLOCK" again to repeat the same operation with the minutes. Then press button "CLOCK" to logoff.
3. Press button CLOCK to show the time when the radio is under RADIO or AUX mode, then it will be back to frequency display after 5 seconds.

B. Alarm Function.

1. Alarm adjusting: Press button "ALARM", then alarm is in "on", and so does the LED display of the alarm. Press again the alarm button to put it off.
To set up the alarm, please press the "ALARM" button for 3 seconds, then follow the same procedure as the time adjusting.
After setting the alarm, the alarm will be automatically on .
2. Alarm mode choosing
Turn the back-up button to choose the clock alarm/buzzer alarm function.
3. Alarm reset.
When alarm ringing, press button "POWER", to stop ringing. The alarm set up will be kept and waiting for the next alarm time.
4. SNOOZE: When alarm ringing ,after pressing "SNOOZE", the alarm will ring again 5 minutes later.

C. Radio Mode

1. Press the button "POWER" to turn it on.
2. Press + and - to change the volume.
3. Press AM/FM to interchange AM and FM
4. Press button \wedge or \vee to select channels under the condition of AM or FM. Keep pressing it for 3 seconds to seek the channels automatically.

D. Automatic Channel Saving

When radio "on", press and hold one of the saved channel button (from 1 to 6) for 3 seconds to save a new channels. The LED will flash once after the channel has been saved.

E. AUX IN

Plug AUX in, it will turn automatically in AUX mode.

The standby battery is 3V. It will only have the time memory function when put the batteries in as without DC input.

12-hour style, the different is just showed the time with AM/PM LED lighting.

BAHASA INDONESIA

A. MODE JAM

1. Ketika unit terhubung dengan adaptor, waktu yang ditunjukkan pada layar adalah "0:00"
2. Pengaturan Jam: Setelah 3 detik tekan tombol "CLOCK", layar akan menunjukkan "24:00" and berkedip. Anda dapat memilih sistem 12 jam dengan menekan tombol Δ , setelah memilih sistem operasi jam tekan tombol "CLOCK", angka digital jam akan berkedip. Tekan tombol Δ untuk menaikkan angka jam dan tekan ∇ untuk mengurangi angka jam. Tekan tombol "CLOCK" lagi untuk pengaturan menit dengan pengoperasian yang sama. Tekan tombol "CLOCK" untuk keluar.
3. Tekan tombol "CLOCK" untuk melihat jam ketika dalam mode RADIO atau AUX, lalu akan kembali menunjukkan frekuensi radio kembali setelah 5 detik.

B. MODE ALARM

1. Pengaturan alarm: Tekan tombol "ALARM" untuk mengaktifkan alarm dan menampilkannya pada layar . Tekan tombol "ALARM" kembali untuk menonaktifkan alarm.
Untuk mengatur alarm, tekan tombol "ALARM" selama 3 detik, lalu lakukan prosedur yang sama seperti pengaturan jam. Setelah melakukan pengaturan alarm, alarm akan otomatis aktif.
2. Memilih mode alarm
Putar tombol back-up untuk memilih fungsi alarm/buzzer
3. Reset alarm
Ketika alarm berdering, tekan tombol "POWER" untuk menstop dering. Pengaturan alarm akan tetap tersimpan sampai waktu alarm berikutnya.
4. SNOOZE
Ketika alarm berdering, setelah menekan tombol "SNOOZE", alarm akan berdering 5 menit kemudian.

C. MODE RADIO

1. Tekan tombol "POWER" untuk menyalakan Radio.
2. Tekan "+" dan "-" untuk pengaturan suara,
3. Tekan AM/FM untuk mengganti mode radio AM/FM.
4. Tekan tombol Δ atau ∇ untuk menentukan channel radio AM atau FM. Tekan selama 3 detik untuk pencarian channel radio otomatis.

D. PENYIMPANAN CHANNEL OTOMATIS

Ketika radio nyala, tekan dan tahan salah satu tombol channel (dari 1 sampai 6) selama 3 detik untuk menyimpan channel baru. LED akan berkedip sekali setelah channel disimpan.

E. MODE AUX

Sambungkan kabel AUX untuk menyalakan mode AUX secara otomatis.

Baterai yang diperlukan adalah 3 V. Hanya fungsi *time memory* yang dapat digunakan ketika menggunakan baterai tanpa *DC Input*.

Perbedaan waktu pada sistem 12 jam ditunjukkan oleh AM/PM (Lampu LED).