


## AUTOMATIC

AUTOMATIC

1. Hour hand
2. Minute hand
3. Second hand
4. Month indicator
5. Day of week indicator
6. 24 hour indicator
7. Date indicator

- S1 Month set button  
S2 Date set button  
S3 Day of week set button



### About AUTOMATIC WATCHES:

The AUTOMATIC SELF-WINDING MECHANICAL WATCH is not operated by a battery. You must wind it six or seven times before wearing. After that, your daily activity should wind the watch sufficiently to keep it running at night when it is not being worn. Occasional supplementary manual winding may be necessary. It is suggested that your mechanical watch be cleaned and oiled periodically to insure optimum performance. As this is a mechanical watch, quartz watch accuracy cannot be expected.

### To Wind the MAINSPRING:

1. Hand wind by turning the crown clockwise in "A" position. Wind 15-20 times.
2. The wearer can also wind the watch by moving his/her wrist from side to side several times.

### To Set the TIME:

1. Pull out crown to second click position "B".
2. Turn crown counter-clockwise to correct time.
3. Push in crown to "A" position to set.

Note: Please do not adjust the time during the period from 22:00 to 02:00, it could be harmful for the movement.

### To Set the DAY OF WEEK (Quick Change Function):

1. Press S3 to set the DAY OF WEEK.

### To SET THE DATE (Quick Change Function):

1. Press S2 to set the DATE.

### TO SET THE MONTH:


1. Press S1 to set the MONTH.

AUTOMATIC

## AUTOMATIC 3 HANDS

Diag. A

1. Second Hand
2. Moon Phase Indicator
3. Date Hand

**To Wind the MAINSPRING:**

1. Recommend initial use of watch, hand wind the watch by turning the crown 30 times in position A. The watch will start to move naturally after shaking slightly.
2. The wearer can also wind the watch by moving his/her wrist from side to side several times.

**Note:**

- If the watch does not start yet, wind the crown 5-10 times further in position A, or give a shock slightly to the watch.

**To Set the TIME and the Phase of the Moon:**

1. Pull the crown out to position B.

2. Turn crown to set the hour and minute hands.
3. At the moon phase indicator, please check the Sun and Moon representing AM and PM respectively is set correctly.
4. Push in crown to A to set.

**To Set the DATE:**

Press Pusher A to set the date. (Quick change function)

**Special Handling Instruction:**

1. Water-resistant  
Check the chart to determine the water-resistant properties of this watch.  
Always set the crown in the normal position.  
Do not operate the crown when the watch is wet.
  - Tighten screw-lock crown completely. (Screw-lock type crown)
2. Avoid extreme temperature
3. Avoid strong shocks
4. Avoid strong magnetic fields
5. Avoid chemicals and gases  
Avoid wearing your watch in the presence of chemicals