



In TIME mode you can set time and calendar information within two time zones.



English

BATTERY TYPE: SR626SW Silver Oxide

BATTERY LIFE: The battery in your Nike watch is estimated to last 2 years, depending on frequency and use of certain features.

BATTERY REPLACEMENT: Battery replacement must be performed by an authorized Nike service center to retain a valid warranty. In addition to battery replacement, the service center will test movement, gaskets, water resilience and hardware, to further ensure the long-term care of your watch.

WARNING! Keep watch batteries away from children. If swallowed, contact a doctor immediately.

WARNING! Batteries contain chemical substances.

They should be disposed of properly according to local regulations

WATER RESISTANCE: 50 meters

Built to withstand shallow diving in pools and snorkeling.

ATTENTION: Water damage may occur if the buttons are pressed underwater

OPERATING TEMPERATURE:

-5 to 50° Celsius

Material Specifications

CRYSTAL: Acrylic

STRAP: Plastics

CASE: Polycarbonate

BUTTONS: Plastics ABS

CROWN: Stainless Steel

BUCKLE: Stainless Steel





This document with updates is available online at

www.niketiming.com





In CHRONOGRAPH mode you can record total time during a run or set a countdown timer.



In ALARM mode, you can set one time alarm.

