

En Changes to the D40 Menus

Ck D40 菜单的更改

Ck D40 功能表的更改

Ck D40 菜单的更改

感谢您选购尼康 (Nikon) D40 数码单镜头反光 (SLR) 相机。由于 D40 已通过验证适用于 Windows Vista 操作系统，我们对相机菜单进行了如下更改。所有页码均取自于 *数码摄影指南 D40*。

USB

USB 菜单中的 **PTP** 选项已重新命名为 **MTP/PTP** (第 84 页)。当连接至 PictBridge 打印机 (第 58 页) 或运行 Camera Control Pro (第 56 页) 的计算机时，请选择 **MTP/PTP**。当连接至运行 PictureProject (第 55 页) 的计算机时，请按照下表所示选择 USB 选项。



计算机操作系统	USB
Windows Vista (32 位家用基本版 / 家用高级版 / 商务版 / 企业版 / 最终版) Windows XP (家用版 / 专业版)	选择 MTP/PTP 或 Mass Storage
Mac OS X 10.3.9 或 10.4.x 版	
Windows 2000 专业版	选择 Mass Storage

有关所支持操作系统的最新信息，请访问 *数码摄影指南* 第 x 页所列出的网站。

闪光补偿

拍摄信息显示 (第 48 页) 和个人设定菜单 (个人设定 8, 第 74、76 页) 中的 **闪光级别** 选项已重新命名为 **闪光补偿**。

商标信息


Macintosh 和 Mac OS 为 Apple Computer 公司的注册商标。Microsoft、Windows 及 Windows Vista 为美国及 / 或其它国家 Microsoft 公司的商标或注册商标。

En Changes to the D40 Menus

Thank you for your purchase of a Nikon D40 single-lens reflex (SLR) digital camera. Please note the following changes to the camera menus as a result of the D40 having been certified for use with the Windows Vista operating system. All page numbers refer to the *Guide to Digital Photography with the D40*.

USB

The **PTP** option in the USB menu has been renamed **MTP/PTP** (page 84). Choose **MTP/PTP** when connecting to a PictBridge printer (page 58) or to a computer running Camera Control Pro (page 56). When connecting to a computer running PictureProject (page 55), choose a USB option as described below.



Computer operating system	USB
Windows Vista (32-bit Home Basic/Home Premium/Business/Enterprise/Ultimate editions) Windows XP (Home Edition/Professional) Mac OS X version 10.3.9 or 10.4.x	Choose MTP/PTP or Mass Storage
Windows 2000 Professional	Choose Mass Storage

See the websites listed on page x of the *Guide to Digital Photography* for the latest information on supported operating systems.

Flash Compensation

The **Flash level** options in the shooting information display (page 48) and Custom Settings menu (Custom Setting 8, pages 74 and 76) have been renamed **Flash compensation**.

Trademark Information

Macintosh and Mac OS are registered trademarks of Apple Computer, Inc. Microsoft, Windows, and Windows Vista are trademarks or registered trademarks of Microsoft Corporation in the United States and/or other countries.

Ch D40 功能表的更改

感谢您选购尼康 (Nikon) D40 数位单镜头反光 (SLR) 相机。由于 D40 已被验证适用于 Windows Vista 作业系统，我们对相机功能表进行了如下更改。所有页码均取自于 *数位摄影指南 D40*。

USB

USB 功能表中的 **PTP** 选项已重新命名为 **MTP/PTP** (第 84 页)。当连接至 PictBridge 印表机 (第 58 页) 或运行 Camera Control Pro (第 56 页) 的电脑时，请选择 **MTP/PTP**。当连接至运行 PictureProject (第 55 页) 的电脑时，请按照下表所示选择 USB 选项。



電腦作業系統	USB
Windows Vista (32-bit Home Basic/Home Premium/Business/Enterprise/Ultimate editions) Windows XP (Home Edition/Professional) Mac OS X 10.3.9 或 10.4.x 版	選擇 MTP/PTP 或 Mass Storage
Windows 2000 Professional	選擇 Mass Storage

有關所支援作業系統的最新資訊，請參考 *數位攝影指南* 第 x 頁所列出的網站。

商標資訊

Macintosh 和 Mac OS 為 Apple Computer 公司的註冊商標。Microsoft、Windows 及 Windows Vista 為美國及 / 或其他國家 Microsoft 公司的商標或註冊商標。