OXO GOOD GRIPS®

INSTRUCTIONS FOR USE

To set clock:

1. Press and hold clock/timer button for 3 seconds (clock icon will appear on left side of screen).
2. Input time using keypad then quickly press clock/timer button to save.

To set timer:

1. Press and release clock/timer button.
2. If necessary, press clear/memory so timer reads all zeroes.
3. Enter desired time using keypad (to a maximum of 99hrs:99mins:99secs).
4. Press stop/start to begin countdown.
5. Pause countdown by pressing stop/start; resume by pressing button again.
6. When countdown is complete, timer will beep continuously for 30 seconds and display will flash. Timer will then beep every 10 seconds for 10 minutes until the stop/start button is pressed.
7. Press clock/timer button to return to clock function.

To time activities:

1. Press and release clock/timer button.
2. If necessary, press clear/memory so timer reads all zeroes.
3. Press stop/start and plus (+) sign will appear on right side of screen as timer begins counting up.
4. Pause count-up by pressing stop/start; resume by pressing button again.
5. When you're finished timing, press stop/start to end timing function.
6. Press clock/timer to return to clock function.