

Text/Legend

Failure Display POINT		
Appliances with 1 and 2-digit 7 Segment Display and without 7 Segment Display		
Alarm / Failure	Failure code, indication in test program when a failure occurs	
	Shown with 7 segment display or without 7 segment display	Shown on 2/3 digit 7 segment display
F1 NTC-Failure	START ☼ 1 x flash 1s Pause 1 x flash.....	F1
F2 Water Leakage	START ☼ 2 x flashes 1s Pause 2 x flashes.....	F2
F3 Failure in Heating System	START ☼ 3 x flashes 1s Pause 3 x flashes.....	F3
F4 Draining Failure	START ☼ 4 x flashes 1s Pause 4 x flashes.....	F4
F6 Water Tap closed	START ☼ 6 x flashes 1s Pause 6 x flashes.....	F6
F7 Flow Meter Failure	START ☼ 7 x flashes 1s Pause 7 x flashes.....	F7
F8 Water Level Failure	START ☼ 8 x flashes 1s Pause 8 x flashes.....	F8
F9 Continuous Waterinlet	START ☼ 9 x flashes 1s Pause 9 x flashes.....	F9
F0 Sensor-Failure (Only displayed in act. test program)	START ☼ 10 x flashes 1s Pause 10 x flashes.....	F0
FA OWI-Fehler	START ☼ 11 x flashes 1s Pause 11 x flashes.....	FA
FB MDV-Fehler	START ☼ 12 x flashes 1s Pause 12 x flashes.....	FB
FC ASA-Fehler (Only displayed in act. test program)	START ☼ 13 x flashes 1s Pause 13 x flashes.....	FC

☼ LED flashing

- "Rotor blocked (F5)" isn't displayed on the POINT appliance