

5.4 Edit a Phonebook Entry
1. Press <MENU> then <UP/DOVW> to select PHONEBOOK and then press <OK> to access the phonebook.
2. Press <MENU> and <UP/DOVW> to select the desired phonebook entry.
3. Press <MENU> and <UP/DOVW> to select EDIT.
4. Press <OK> to display the current name.
5. Edit the name and press <OK>.
6. Edit the number and press <OK>.
7. Press <UP/DOVW> to select the ringtone and press <OK> to confirm.
8. Press <OK> to access the phonebook.

5.5 Delete a Phonebook Entry
1. Press <MENU> then <UP/DOVW> to select PHONEBOOK and then press <OK> to access the phonebook.
2. Press <MENU> and <UP/DOVW> to select the desired phonebook entry.
3. Press <MENU> and <UP/DOVW> to select DELETE.
4. Press <OK> to confirm, and the entry will be deleted.
5. Press <UP/DOVW> to select the ringtone and press <OK> to confirm.

5.6 Delete All Phonebook Entries
1. Press <MENU> then <UP/DOVW> to select PHONEBOOK and then press <OK> to access the phonebook.
2. Press <MENU> and <UP/DOVW> to select DELETE ALL.
3. Press <OK> to confirm, and all entries will be deleted and the display will show EMPTY.
4. Press <UP/DOVW> to select the ringtone and press <OK> to confirm.
5. Press <OK> to access the phonebook.

5.7 Check the Phonebook Usage
You can check how many phonebook entries are stored in your handset and how many phonebook entries are available for you to store in the phonebook.
1. Press <MENU> then <UP/DOVW> to select PB STATUS.
2. Press <OK> to display how much of the phonebook is being used.
For example: 6 / 20 (USED=6 means 6 entries are stored out of the total 20 available spots).

6 CALLER DISPLAY (NETWORK DEPENDENT)
This feature is available if you are subscribed to the Calling Line Identification service with your network service provider. Your phone can store up to 10 received calls with optional information in the Call List. The number will be shown on the handset display when the phone is ringing. If the number matches with one of the entries in your Phonebook, the caller's name stored in the private phonebook will be displayed alternately with the number, and the handset will ring with the ringtone associated with that phonebook entry. If the call is from someone whose number, e.g. by dialling 111, "WITHELU" will display.
If the call is from someone whose number is unavailable, e.g. an international call or from a private exchange, "OUT OF AREA" will display.
If you've got New Caller Display records, the handset will display "X NEW CALLER" in standby mode. The New Calls indication will remain until all the new call records have been viewed on the handset.
6.1 View the Call List
All received calls are saved in the Call List, with the latest call at the top of the list. When the call list is full, the oldest call will be marked with a "1" next to the number of the call. Press <OK> to go back to the previous screen.
6.2 Store a Call List Number into the Phonebook
1. Follow Steps 1 and 2 in Section 6.1.
2. Press <MENU> and <UP/DOVW> to show ADD TO PB.
3. Press <OK> and then enter the number.
4. Press <OK> and the selected call list number is assigned.
5. Edit the number if necessary.
6. Press <OK> and <UP/DOVW> to select DETAILS and then <OK> to display the date and time of the call. Press <OK> to go back to the previous screen.
6.3 Delete an entry in the Call List
1. Follow Steps 1 and 2 in Section 6.1.
2. Press <MENU> and <UP/DOVW> to select DELETE.
3. Press <OK> to confirm.
4.4 Delete all Call list entries
1. Follow Steps 1 and 2 in Section 6.1

7 PHONE SETTINGS
Your phone comes with a selection of settings that you can change to personalise your phone the way you like to use it.
7.1 Date and Time Settings
If you subscribe to Caller Display, the date and time settings will be automatically updated by the network when you receive an incoming call.
The Caller Display service only sends the month and date, not the year, so you may need to set the year.
7.1.1 Change the Date Format
1. Press <MENU> and <UP/DOVW> to select DATE & TIME.
2. Press <OK> to confirm. All entries will be deleted and the display will show EMPTY.
3. Press <MENU> and <UP/DOVW> to select DATE FORMAT.
4. Press <OK> to confirm.
5. Press <OK> to confirm.

7.2 Alarm Settings
You can set an alarm time on the handset. When an alarm is set, the <ALARM LOOP> is shown on the handset display. When the alarm time is reached, the <ALARM LOOP> flashes on the handset display, and the alarm tone rings for 45 seconds. You can press any key to disable the alarm. If the snooze function is activated, the alarm will sound again at the end of the snooze period of seven minutes. You can also press and hold <TALK OFF> while the alarm is sounding, to stop the alarm and turn off the snooze function.
Note: The respective melody will be played while browsing the ringtone list.
7.2.1 Turn on/off the Alarm
1. Press <MENU> and <UP/DOVW> to select ALARM.
2. Press <OK> to confirm.
3. Press <MENU> and <UP/DOVW> to select ALARM ON/OFF.
4. Press <OK> to confirm.
5. Press <OK> to confirm.

8 ANSWERING MACHINE
Your phone includes a built-in answering machine that records unanswered calls when it is in the answering machine mode. The maximum recording time is up to 15 minutes, depending on which handset mode is selected.
8.1 Turn On/Off the Answering Machine
1. Press <MENU> and <UP/DOVW> to select ANSWERING MACHINE.
2. Press <OK> to confirm, and the display will show SEARCHING.
3. Press <OK> and you are requested to enter the 4-digit system PIN.
4. Press <OK> and you are requested to enter the 4-digit system PIN.
5. Press <OK> and you are requested to enter the 4-digit system PIN.
6. Press <OK> and you are requested to enter the 4-digit system PIN.
7. Press <OK> and you are requested to enter the 4-digit system PIN.
8. Press <OK> and you are requested to enter the 4-digit system PIN.
9. Press <OK> to confirm.

8.2 Listen to Messages in the Answering Machine
When new messages are recorded on the answering machine, the <TAM COPIES> on the handset display will be saved as an old message automatically unless it is deleted.
Old messages will be played after new messages are played completely unless it is deleted.
8.3 Record Message
When you record your own message for another user. When you record a message, the play button can be played back the same way as answering machine messages. Memo recording can still function even when the answering machine is turned off.
8.4 Record Memo
When you record your own message for another user. When you record a message, the play button can be played back the same way as answering machine messages. Memo recording can still function even when the answering machine is turned off.

9 TROUBLESHOOTING
Problem Description Solution
... (table with 3 columns: Problem, Description, Solution) ...

10 DECLARATION OF CONFORMITY
The manufacturer / importer (Bosch Mobile Telecom P.C., 1 Amstel Yacht London, NINE 7HF, United Kingdom) declares under sole responsibility that the following product:
Type of equipment: Digital cordless telephone
Model name: Lifestyle 1910 Series
Country of Origin: Bosnia
Country of Manufacture: Bosnia
Complies with the essential product requirements of R&TTE Directive 1999/5/EC on the approximation of the laws of the Member States relating to Radio Spectrum Matters, the Council Directive 2004/108/EC on the approximation of the laws of the Member States relating to electromagnetic compatibility (EMC) and the European Community Directive 2002/95/EC relating to a restriction of use of certain substances
Assessment of compliance of the product with the requirements relating to the essential requirements specified in article 19(2) is made based on Annex II of the Directive 1999/5/EC and the following statement:
EMC: EN 301489-1 V1.1 2005
EN 301489-2 V1.1 2005
EMC: EN 60950-1
EMC: EN 60950-2
Manufacturer responsible for technical documentation: Date: 10/08/2009
(Signature of authorised person) Date: Signature
This conforms to the requirements as validated by the CE symbol.
NOTE: In compliance with Directive 2006/66/EC, when you purchase a product of BOSCH, you are guaranteed that you are purchasing a product that cannot display any of the following defects:
- It does not contain any hazardous substances in quantities that exceed the limits set in the relevant legislation.
- It does not contain any hazardous substances in quantities that exceed the limits set in the relevant legislation.
- It does not contain any hazardous substances in quantities that exceed the limits set in the relevant legislation.
- It does not contain any hazardous substances in quantities that exceed the limits set in the relevant legislation.
- It does not contain any hazardous substances in quantities that exceed the limits set in the relevant legislation.

11 GUARANTEE AND SERVICE
The Lifestyle 1910 system is guaranteed for 12 months from the date of purchase under any sales receipt. This guarantee does not cover any faults or defects caused by accidents, misuse, fire, war and sea, neglect, theft or any telephone line, lightning, tampering with the equipment, or any attempt at adjustment or repair after thorough approval agreements. You should also keep the original packaging material.
11.1 While the unit is under GUARANTEE
1. Disconnect the base unit from the telephone line and take the mains electricity supply.
2. Pick up all parts of your Lifestyle 1910 system, using the original packaging.
3. Return your Lifestyle 1910 system to the address given by your sales receipt.
11.2 After the Guarantee has expired
If the unit is no longer under GUARANTEE, follow steps 1 and 2 as for repair under GUARANTEE. Then:
3. Call Helpline on 0845 345 9677 (UK only) and ask for a quotation of the repair charge and details of how to send your Lifestyle 1910 system for repair.
4. Make sure you include your Lifestyle 1910 system.
5. Your name and address.
6. A cheque or postal order for the value of the repair.
7. A brief description of the fault.
8. Return your Lifestyle 1910 system to the address given by the Service Department.
9. This does not affect your statutory rights.