

Bluetooth Headset

Latte Mocha Series User Manual



LATE™

[Table of contents]

Before use

Package contents	2
Description of parts	3
Wearing	4
Charging	4
Low battery	4

How to use

Power on	5
Power off	5
Pairing	5
Connecting	7
Answering a call	8
Making a call	8
Ending a call	9
Volume control	9
Functions during a call	9
Summary of button functions	11
LED indication and signal sound	12


Supplement

Troubleshooting	13
Cautions	14
Additional information	16
Standard and specification	18
Limited warranty	19


The Latte Bluetooth headset Mocha is a lightweight and compact wireless connectivity device. The DSP (digital signal processor) feature of the Latte Mocha Series offers superior audio performance via noise reduction and echo cancellation. The Latte Mocha Series is compatible with most Bluetooth mobile phones that support the “headset” and/or “hands-free” profile(s).

[Package contents]


Ensure that the items mentioned below are all included in the package. If any item is missing, please contact the dealer.



Bluetooth headset




User manual



Charger

[Description of parts]



[Wearing]


The ear loop of the Latte Mocha Series can be rotated and adjusted to fit on either the left or the right ear, as shown below.



Left




Right



[Charging]

- Open and twist the cover on the charging port, as shown below.



- Insert the charger completely into the charging slot until the status LED glows red. Note that connecting the charger while the power is on will turn off the headset.
- The buttons on the headset will not function while charging.
- Charge your headset until the status LED turns off. The unit will be fully charged in approximately 2 h.




WARNING: Do not attempt to charge the Latte Mocha Series with any charger other than the one provided. Using another charger may damage or destroy the headset.


[Low battery]

- The status LED will flash red with a beeping sound that would indicate that the battery charge is low.
- Charge the battery as soon as the abovementioned phenomenon is detected.
- The headset will turn off when the battery is not charged.

[Power on]


1. Press and hold  for 2 s.
2. You will hear a booting tone and the status LED will flash blue 5 times briefly and rapidly.

[Power off]

1. Press and hold  for 5 s.
2. You will hear a beep and the status LED will flash blue 5 times briefly and rapidly.

[Pairing]

Before using your headset for the first time, you must pair it with your Bluetooth mobile phone.

1. Begin with the headset turned off; then, press and hold down  for 5 s.
2. You will hear two short beeps, and the status LED will begin to flash red and blue in turn continuously.
3. Go to the Bluetooth menu in your mobile phone and search for either “headset” or “hands-free” (When the headset is connected as a hands-free device, you can use all functions of the Latte Mocha Series).

4. Select “Latte Mocha Series” from the list of searched devices.
5. When prompted for a passkey, enter 0000.
6. A beep will sound when the devices are paired successfully.

The Latte Mocha Series will turn off automatically if it stays in the “pairing mode” for over 3 min without being paired to any device. In this case, you have to reattempt the pairing process (see abovementioned steps). The connection can be made automatically after pairing depending on the features of different models of mobile phones.

[Connecting]


To use the headset after pairing (or after losing the connection), you should connect it to the paired mobile phone. For more details regarding the connection method, please refer to the manual of your Bluetooth mobile phone.

Auto reconnection

1. When the headset turns off while connecting


The headset will be automatically reconnected without the pairing process when power is supplied (the mobile phone connected previously should be within 10 m from the headset).

2. Out of range

The headset will be automatically reconnected when it is brought back within a 10-m range of the mobile phone connected previously within 3 min. If you want to connect immediately, briefly press  once.


- When out of range (greater than 10 m), the connection between the headset and the Bluetooth device will be dropped.
- If the headset and the Bluetooth device have been separated for over 3 min, up to 10 min will be required for auto reconnection.

[Answering a call]

The headset and mobile phone will ring simultaneously when an incoming call is received. You can answer a call by pressing  briefly (The call can also be answered using the mobile phone).



[Making a call]

Voice dialing*

Press and release  once. You will hear the voice-activation tone; say the registered name on the voice dialing list.

- This function is only available if your mobile phone supports the voice dialing function and the headset is paired as a hands-free device.
- If your mobile phone does not support voice dialing, the headset will activate the last number redial feature. The headset may not activate any action; this again depends on the features of different models of mobile phones.



Last number redialing *

Press and hold  for 1 s; this will activate the last number redial feature. Subject to different models of mobile phone, it will show you the recently dialed call list; then, you can briefly press  again to make a call.

[Ending a call]



To end a call, briefly press .

[Volume control]



Briefly press the volume up  or volume down button  located at the side of the headset in order to control the speaker volume. Eight levels of volume control are available.

[Functions during a call]

Transferring a call*

Briefly press  to transfer a call from your mobile phone to your headset while on a call (the headset and the mobile phone must be connected prior to this process). To transfer a call from your headset to your mobile phone, press and hold the volume up button  for 5 s.



Call waiting*


Answer the second incoming call without ending the first call by pressing  for 1 s. To return to the first call, simply press  again for 1 s.

Call reject*
















To activate the call reject function, press  for 1 s when an incoming call is detected.

Mute

To activate the mute function, press the volume down button  for 5 s. When the call mute function is activated, the other party will not be able to hear your voice; however, you will still be able to hear their voice. Further, you will hear a beep periodically. To release the call mute function, press the volume down button  for 5 s again.

-  The *(star) mark indicates that these functions are only available with a hands-free profile, and the connected mobile phone should support these functions. For additional information regarding these functions, refer to the user manual of your Bluetooth mobile phone.

[Summary of button functions]





Function	Headset status	Action
Power on	Power off	Press  for 2 s
Power off	Power on	Press  for 5 s
Volume up	Talking	Briefly press the volume up button 
Volume down	Talking	Briefly press the volume up button 
Transferring a call	Talking	- From the mobile phone to the headset: Briefly press  once - From the headset to the mobile phone: Press and hold the volume up button  for 5 s
Answering a call	Ringing	Briefly press 
Ending a call	Talking	Briefly press 
Call waiting	Talking	Press  for 1 s
Last number redialing	Idle	Press  for 1 s
Voice dialing	Idle	Briefly press 
Call reject	Ringing	Press  for 1 s
Pairing	Power off	Press  for 5 s
Mute on	Talking	Press the volume down button  for 5 s
Mute off	Mute	Press the volume down button  for 5 s

[LED indication and signal sound]

Function	Signal Sound	Status of LED
Power on	Booting tone	The LED flashes blue 5 times rapidly
Power off	Shutdown tone	The LED flashes blue 5 times rapidly
Pairing	Beeps twice	The LED flash red and blue in turn continuously
When the headset and mobile phone is connected and when the user is talking on the headset	No beep	The LED flashes blue twice every 5 s
Unintentional loss of connection (until the connection is recovered)	Beeps periodically	The LED flashes purple (blue and red) once every 5 s
Charging	No beep	The red LED is on
Charging completed	No beep	The red LED is off
Battery power is low	Beeps periodically	The blue LED turns red

[Troubleshooting]

In case the headset does not function correctly, please follow the corrective action given in the table below. If the problem is not solved even after performing the corrective actions, please contact the dealer from whom the headset was purchased.

Status	Signal Sound	Corrective action
Power on	Check whether the battery of the Latte Mocha Series headset is charged	The LED flashes blue 5 times rapidly
Unable to communicate using the headset	Check whether your mobile phone supports the "headset" and/or "hands-free" profile(s)	Your mobile phone should support "headset" and/or "hands-free" profile(s) to use the Latte Mocha Series
	Check whether the battery is fully charged	Charge the battery if the battery power is low
Unable to pair the Latte Mocha Series headset with a Bluetooth mobile phone	Check whether the headset is on	Press  for 2 s to turn on the headset
	Check whether the headset is in the pairing mode	With power off, press and hold  for at least 5 s to place the Latte Mocha Series in the pairing mode
Extremely low or loud speaker volume	Check the speaker volume	Press either the volume up button  or the volume down button  to control the volume accordingly

[Cautions]

1. Do not drop the unit from a height.



2. Do not modify, repair, or take apart this unit.



3. Do not expose this unit directly to water, alcohol, benzene, etc. for cleaning.




4. Do not expose this unit directly to flammables.



5. Do not place this unit near flammables.



6. Protect this unit from humidity and dust.



7. Do not place a heavy object on this unit.



- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- There is a risk of explosion if the battery is replaced by an incorrect type.
- The ear loop is made of durable plastic that does not break but bend. However, frequent bending of the ear loop is not recommended.



In order to ensure the best performance and to prevent any damage to or misuse of the Latte Mocha Series unit, please read the complete information provided in this user manual carefully prior to using it.

Any modifications or changes in this manual due to typographical errors or inaccuracies in the stated information shall only be made by Latte Communications, Inc.

[Additional information]

- The cover range of wireless communication is within a maximum of 10 m and the conditions vary according to obstacles.
- The Latte Mocha Series can be connected only to those mobile phones that support the Bluetooth “headset” and/or “hands-free” profile(s). This headset is not compatible with the standard cordless phones used in homes.
- As it operates in the same frequency range, the Latte Mocha Series can be affected by the devices that operate in the ISM band (2.402 GHz ~ 2.480 GHz), for example, wireless LAN, microwave devices, medical appliances, etc. Therefore, in order to ensure proper operation, the Latte Mocha Series headset should be away from these devices.
- Please turn off your headset in an area with a potentially explosive atmosphere (oil warehouse, explosive warehouse, etc.). In rare occurrences, this headset could generate sparks. This could lead to an explosion or fire, which could result in bodily injury. Therefore, follow the warning notices in those areas carefully.

- If handled properly, a rechargeable battery can have a long service life. A new battery or one that has not been used for a long period of time could have reduced capacity the first few times it is used.

[Standards and specifications]

Name of product	A wireless device for wireless data communication system (Latte Mocha Series)
Bluetooth specification	V 2.0
Supported profiles	Headset and hands-free profiles
Frequency	2.402 GHz ~ 2.480 GHz (ISM band)
Transmitting output	Class 2
Cover range	Within 10 m/33 ft
Standby time	Up to 170 h
Talk time	Up to 5 h
Charging time	Approximately 2 h
Operation temperature	-10°C ~ 55°C
Charger rated voltage input	AC 100 V ~ 220 V, 50 Hz ~ 60 Hz
Dimension/Weight	43.9(L) × 18.4(W) × 14.9(H) mm/11 g

*The standard usage time of the battery can vary depending on the usage condition of the mobile phone.

[Limited warranty]

- Subject to the conditions of this limited warranty, Latte Communications, Inc. warrants this product as follows based upon the compensation regulations for damage by users.
- Should your product require warranty service, please contact the dealer from whom the product was purchased.

Product Name	Bluetooth Headset	Model Name	Latte Mocha Series
Purchase Date		Dealer	
Serial No.		Purchase Price	

[Free service]

If the product malfunctions in spite of proper usage, the warranty is valid only within the limited warranty period of one (1) year from the original purchase date. This warranty includes free repair or replacement. Please present the purchase receipt to the dealer for verification of the purchase date.

[Charged service]

- After the limited warranty period has expired.
- Any malfunction due to misuse, repair, or modification by the user.
- Malfunction caused by improper power use.
- Malfunction due to natural disasters such as fire, floods, lightning, etc.
- Once the lifetimes of the expendable parts have ended.

FCC NOTICE TO USERS:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Users are not permitted to make changes or modify the device in any way. Changes or modifications not expressly approved by Latte Communications, Inc. will void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technical for help.

The user must place the base 8" (20 cm) or more from any personnel in order to comply with FCC RF exposure requirements.



FCC ID: UXZHCM100





Latte Communications, Inc.
<http://www.lattefone.com>

Latte Mocha Series User Manual