

## **OLYMPIA® Info Globe**

## **OWNER'S MANUAL**



### **Copyright**

© 2002, Wave Industries Ltd. All Rights Reserved.

Reproduction, adaptation, or translation without prior written permission is prohibited, except as allowed under the copyright laws.

First Edition: August 2002

### **Trademark Information**

Olympia® is a registered trademark of Olympia International Holdings Ltd.

### **Disclaimer**

The information contained in this document is subject to change without notice. Wave Industries makes no warranty of any kind with respect to this information. Wave Industries shall not be liable for any direct, indirect, incidental, consequential, or other damage alleged in connection with the furnishing or use of this information.

Printed in China

### **Contents**

|  |       |
|--|-------|
| <b>Important Notes and Safety Instructions</b> ..... | 3     |
| <b>Features</b> .....                                | 4     |
| <b>Main Unit</b> .....                               | 5     |
| <b>Getting Started</b> .....                         | 6     |
| <b>Normal Standby</b> .....                          | 7-8   |
| <b>Demonstration Mode</b> .....                      | 9     |
| <b>Time and Date</b> .....                           | 9     |
| Setting Time Mode .....                              | 9     |
| Setting Date Format .....                            | 9     |
| Setting Time and Date .....                          | 9     |
| <b>Daylight Saving Time</b> .....                    | 10    |
| <b>Personal Messages</b> .....                       | 11    |
| Programming Personal Messages .....                  | 11    |
| Setting Date of Message Display .....                | 12    |
| <b>Caller ID</b> .....                               | 12    |
| Receiving Caller ID .....                            | 13    |
| Viewing Caller ID List .....                         | 13-14 |
| <b>Trouble Shooting</b> .....                        | 15    |
| <b>Consumer Information</b> .....                    | 16-17 |
| <b>Warranty</b> .....                                | 18    |

## **IMPORTANT NOTES AND SAFETY INSTRUCTIONS**

When using your telephone equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock and injury to persons, including the following:

- Do not use this product near water, for example, near a bath tub, wash bowl, kitchen sink, or laundry tub, in wet basement, or near a swimming pool.
- Avoid using a telephone other than a cordless type) during an electrical storm. There may be a remote risk of electric shock from lightning.
- Do not use the telephone to report a gas leak in the vicinity of the leak.
- Use only the power cord and batteries indicated in this manual. Do not dispose of batteries in a fire. They may explode. Check with local codes for possible special disposal instructions.

### SAVE THESE INSTRUCTIONS

- To prevent personal injury, damage to the unit, or other harm, read this manual in its entirety before operating the Info Globe.
- Do not open the transparent cover and do not use it to lift or handle the message box.
- This product is not a toy. Please keep it out of the reach of children.
- Operation of this product in a manner inconsistent with the instructions given in this manual may result in personal injury and/or damage to the product and will void the warranty.
- There are no user serviceable parts inside. Trying to open and/or alter the product will void the warranty and may result in the equipment being illegal to operate according to FCC regulations.
- During normal operation the Info Globe produces slight vibrations, some of which are transmitted to the resting surface. This may cause other objects to creep/walk, fall, and/or break. Certain objects, such as compact disc players, may malfunction due to the vibrations.
- For those who may experience headaches, dizziness, and/or other medical problems when viewing flickering lights such as television screens and moving message display systems precaution should be taken while viewing the Info Globe display.
- The rotating rod can take up to 30 seconds to begin steady rotations.
- Some people get charged with static electricity when walking on carpeted floors, rub against certain fabrics, etc. Do not touch the Info Globe when electrically charged.
- When the battery becomes weak the device shows BATTERY LOW. The user then needs to insert a new 9V battery and connect to connectors inside the battery compartment.
- The battery provides back up for time, date and message waiting settings during power outage.

## **FEATURES**

- Caller ID Indication - up to 76 records
- Real-time Clock
- Floating Messages (up to 36 characters)
- Built-in Year-round Greetings
- 100-year calendar
- User Programmable Alert Messages
- Automatic Daylight Savings Time Adjustment
- Demonstration Mode
- Battery backup

## **MAIN UNIT AND KEY CONTROLS**

### **LEFT**

- Power up/ down  
Press and hold key for at least 1 second (real time and caller ID are still supported during power down).
- Press to go to left character setting.
- Start/stop rotation in CID list view.

### **RIGHT**

- Press to start Demonstration Mode.
- Press to go to right character setting.
- Delete record(s) in CID list view.

### **SELECT**

- Press to enter into menu entries for menu selection. Use UP/DOWN keys to locate desired setting.
- Press to confirm menu entry.
- Press again after confirmation to go back to main menu.

### **UP/DOWN**

- Press to select previous / next page or character in setting.

## **GETTING STARTED**

THE USER MUST MAKE SURE THAT A QUALITY 9V WORKABLE BATTERY IS WELL CONNECTED INSIDE THE BATTERY COMPARTMENT BEFORE PLUGGING INTO THE ELECTRICAL OUTLET.

- 1) Place the Info Globe on a firm and level surface.
- 2) To optimize the dramatic effect of the display, position the Info Globe against a dark 3-D background, such as books, plants. This will enhance the floating effect and display-contrast.
- 3) Put the battery into the battery compartment and connect to the connectors inside the battery compartment.
- 4) Connect the power adapter and telephone cord into matching jacks on the under side of the base.
- 5) Plug the power adapter into the electrical outlet. Plug the telephone cord into the telephone socket.
- 6) The Rod inside the device starts rotation.
- 7) Once rotation is steady, the LED turns on with the standby display.
- 8) The Info Globe is now in the normal standby mode.

## NORMAL STANDBY MODE

During Normal Standby Mode the following are displayed.

### Caller ID Information

#### New Calls

The number of new calls in the call log will be indicated as shown:

**There are 5 New Calls in Call Log**

#### Details of Last New Message

**Call on 11/04 12.30am>1234567 Johnny**

#### Message Waiting

**Message Waiting**

Note: Message Service needs to be subscribed from Telephone Company.

### Time Display

This shows the time and date as set.

### Messages

Built-in Time related Year-round Greetings

**Good Morning**

During 00:00 ~ 11:59

**Good Afternoon**

During 12:00 ~ 16:59

**Good Evening**

During 17:00 ~23:59

### User programmable Messages

Users can program up to 3 messages to display at particular dates.

As an example, **HELLO WORLD**

### Olympia Info Globe

This is shown when there are no messages. **OLYMPIA Info Globe**

## Built-in Year related Year-round Greetings

As an example for the year 2002

| Date                                   | Holiday           | Greetings   |
|--|-------------------|---|
| 01Jan                                  | New Year's Day    | Happy Holidays<br>Happy New Year                    |
| 02Jan                                  |                   | Wishing You A Prosperous New Year<br>Happy New Year |
| 03Jan                                  |                   | Wishing You A Prosperous New Year<br>Happy New Year |
| 14Feb                                  | Valentine's Day   | Happy Valentine's Day                               |
| 01Apr                                  | Fool's Day        | April Fool's Day! Have a fun day                    |
| 12May                                  | Mother's Day      | Happy Mother's Day                                  |
| (the 2 <sup>nd</sup> Sunday of May)    |                   |   |
| 24May                                  |                   | Have a happy Memorial Day weekend                   |
| (Friday before Memorial Day)           |                   |   |
| 25May                                  |                   | Have a happy Memorial Day weekend                   |
| (Saturday before Memorial Day)         |                   |   |
| 26May                                  |                   | Have a happy Memorial Day weekend                   |
| (Sunday before Memorial Day)           |                   |   |
| 27May                                  | Memorial Day      | Have a happy Memorial Day weekend                   |
| (the last Monday in May)               |                   |   |
| 16Jun                                  | Father's Day      | Happy Father's Day                                  |
| (the 3 <sup>rd</sup> Sunday of June)   |                   |   |
| 04Jul                                  | Independence Day  | U.S. Independence Day Celebration                   |
| 30Aug                                  |                   | Have a happy Labor Day weekend                      |
| (Friday before Labor Day)              |                   |   |
| 31Aug                                  |                   | Have a happy Labor Day weekend                      |
| (Saturday before Labor Day)            |                   |   |
| 01Sep                                  |                   | Have a happy Labor Day weekend                      |
| (Sunday before Labor Day)              |                   |   |
| 02Sep                                  | Labor Day         | Have a happy Labor Day weekend                      |
| (First Monday in September)            |                   |   |
| 08Sep                                  | Grandparent's day | Have A Grand Grandparents Day                       |
| (The Sunday after Labor Day)           |                   |   |
| 31Oct                                  | Halloween         | Boo..Have A SPOOOOKY Halloween!                     |
| 28Nov                                  | Thanksgiving Day  | Turkey Days Are Here! Happy Thanksgiving            |
| (the 4 <sup>th</sup> Thursday of Nov.) |                   |   |
| From 29Nov                             |                   | Happy Holidays                                      |
| (the day after Thanksgiving day)       |                   |   |
| to 28Dec                               |                   |   |
| 29Dec                                  |                   | Wishing You A Prosperous New Year<br>Happy Holidays |
| 30Dec                                  |                   | Happy Holidays                                      |
|  |                   |   |
|  |                   | Wishing You A Prosperous New Year                   |
|  |                   |   |
| 31Dec                                  |                   | Wishing You A Prosperous New Year<br>Happy Holidays |

## **DEMONSTRATION MODE**

This allows the user to view a selection of seasonal greetings appropriate to the occasion.

This includes:

- 01 January (New Year's Day)
- 14 February (Valentine's Day)
- 01 April (Fool's Day)
- 04 July (Independence Day)
- 31 October (Halloween)
- 25 December (Christmas Day)

To activate and deactivate Demonstration Mode press RIGHT key.

Note:

Caller ID information can still be received in this mode.

The SELECT key is disabled in this mode.

## **TIME & DATE**

### **Setting Time Mode**

The clock can be set to run on a 12-hour or 24-hour basis.

1. Press SELECT key to enter the menu.
2. Select SET TIME MODE in menu.
3. Press SELECT key to confirm selection.
4. Use the UP or DOWN key to toggle between 12 and 24-hour clock.
5. Confirm selection by pressing SELECT.

### **Setting Date Format**

Users can choose to have the order of month and day set in the date.

1. Press SELECT key to enter the menu.
2. Select SET DATE FORMAT in menu.
3. Press SELECT key to confirm selection.
4. Use the UP or DOWN keys to set the order of day and month.
5. Confirm selection by pressing SELECT.

### **Setting Time and Date**

1. Press SELECT key to enter the menu.
2. Select SET DATE TIME MODE in menu.
3. Press SELECT key to confirm selection.
4. The Day or Month field is blinking. Use the UP and DOWN keys to select Day or Month.
5. Use the RIGHT key to move along the string to the next location.
6. The Day or Month field is blinking. Use the UP and DOWN keys to select Day or Month.
7. Use the RIGHT key to move along the string to the next location.
8. The Year field is blinking. Use the UP and DOWN keys to select Year.
9. Use the RIGHT key to move along the string to the hour location.
10. The hour field is blinking. Use the UP and DOWN keys to select hour.
11. Use the RIGHT key to move along the string to the minute location.
12. The minute field is blinking. Use the UP and DOWN keys to select minute.

Note: The order of Day or Month will depend on Date Format set.

Time is also set upon receiving Caller ID information if the year has already been set.

## **DAYLIGHT SAVING TIME**

The Info Globe features a hundred-year calendar with an automatic Daylight Saving Time (D.S.T) adjustment.

Daylight Saving Time begins at 2am on the first Sunday of April. Time reverts to standard time at 2am on the last Sunday of October.

That is, on the first Sunday of April, the clock increments from 1.59am to 3am. On the last Sunday of October, the clock falls back from 1.59am to 1am. This is done automatically when the feature is enabled. If the feature is off, the clock increments normally from 1.59am to 2am.

1. Press SELECT key to enter into menu.
2. Select SET DST in the Menu. The current setting is shown.

**DST: ON**

or

**DST: OFF**

The ON/OFF Field is blinking.

3. Press the UP or Down keys to toggle between ON and OFF.
4. Press SELECT to confirm selection.

Note:

The default value after power failure is Off

## **PERSONAL MESSAGES**

### **Programming Personal Messages**

A maximum of 3 messages may be set in the following way.

1. Press SELECT key to enter the menu.
2. Select SET MESSAGE in Menu.
3. Press SELECT to confirm.
4. The MSG1 characters are blinking.
5. Use the UP and DOWN keys to switch between MSG1, MSG2 and MSG3.
6. Press SELECT on the chosen message.

### **To Set Rate of Appearance of Message**

The current rate of appearance of the message is indicated:

E.g. DAILY

**MSG1: Daily**

Displayed on Feb 2.

**MSG1: Feb 2**

Use the UP DOWN keys to toggle between either daily appearance and programmable date of appearance.

7. To select daily appearance press SELECT key to confirm.
8. To set date use the LEFT and RIGHT keys to toggle between Month and Date.
9. The chosen field will blink and the UP and DOWN keys can be used to locate the appropriate Month or Date.
10. Press SELECT to confirm frequency of display and it will be ready for programming message with the following display

**MSG1:**

### **To Program Message**

11. Use the UP and DOWN keys on the blinking field to scroll through the upper and lower case letters of the alphabet and numbers 0-9.
12. Use the RIGHT key to move onto the next character. The LEFT and RIGHT keys may also be used to find the desired location for reselecting and editing.

Note:

At any time during programming, Timeout or an incoming call will put the device into Standby mode. The setting is saved.

## **ERASE ALL MEMORIES**

The following procedure erases the Caller ID list and user programmed messages. Date, Time, Time Mode, Date Format, and DST are retained.

1. Select ERASE MEMORY in the Menu.
2. The word ERASED appears for 1 second and then returns to Standby Mode.

## **CALLER ID**

(Note: This function applies only if you subscribe to a caller ID service)

The Info Globe at all times, except during battery low and power down, will detect ringing with Caller ID. Twenty seconds after Caller ID information is received it will return to Standby.

Caller ID information will be received and stored in the call log which has a maximum number of 76 memories of 16 digits and 10 characters.

The last Caller ID received will be the first to be shown in the list.

When the Caller ID list is full the oldest caller ID is automatically deleted and the most recent caller ID is added.

The following are possible Caller ID messages:

|                 |  |
|-----------------|--|
| UNAVAILABLE     | Call from an area which does not provide caller ID information   |
| PRIVATE         | The other party is blocking name and number information  |
| PUBLIC          | Call from public payphone  |
| LONG DISTANCE   | Long distance phone call   |
| MESSAGE WAITING | There is a message left by a caller (requires subscription to telephone company for messaging services). |

Please see below for illustrations.

### **Viewing CID List**

1. In Menu select CIDLIST.

The most recent caller ID is shown first.

The following are messages that may be shown.

**01>11/4 12.30am - 123456 Johnny**

CID with Name and Number

**02>11/4 12.30am - 123456**

CID with Number Only

**03>11/4 12.30am - Private**

CID with Reason of Absence of Number.

**04>11/4 12.30am - Message Waiting**

CID with Message Waiting Only.

**05>11/4 12.30am - MW 123456**

CID with Message waiting and Number available.

**No CID**

There is no CID information

Note:

For records that have a total number of characters and digits exceeding that, which can be stored, part of the message will be truncated.

Pressing the UP key, displays the previous record in the Caller ID list. At the beginning of the Caller ID List, pressing the UP key will go to the last selection.

Pressing the DOWN key displays the next record in the Caller ID list. At the end of the Caller ID List, pressing the DOWN key will go to the top of the list.

Pressing RIGHT key once will delete the current displayed record

Pressing and holding the RIGHT key for 2 seconds during Caller ID browsing, the following will be displayed:

**DELETE ALL?**

Pressing the RIGHT key again will delete all CID records.

If the RIGHT key is not pressed for 10 seconds the Info Globe will go back to the Caller ID list view.

## **TROUBLE SHOOTING**

1. There is no rotation and display after plugging into an electrical outlet.  
Ensure that the AC adaptor is plugged in properly and batteries are installed properly.
2. There is no Caller ID information being received.  
Check that Caller ID service is subscribed from Telephone Company. Ensure that telephone cord is plugged in correctly.
3. There are sounds of vibration coming from base.  
Vibrations coming from the Info Globe are normal. However, check that the device is standing firmly on a level surface and that there are no other objects close to the Info Globe that may be producing the sound.
4. Floating display looks faint  
Check that AC adapter has been plugged in properly. Place Info Globe against a dark background to obtain maximum illumination from floating display.
5. Time and date are not retained during power outage.  
Replace battery and install a fresh one properly.

## **CONSUMER INFORMATION**

This equipment complies with Part 68 of the FCC rules and the requirements adopted by the ACTA. On the bottom of this equipment is a label that contains, among other information, a product identifier in the format US: 2X6ND01BOL3000NNN.

An applicable certification jacks Universal Service Order Codes (USOC) for the equipment is provided (i.e., RJ11C) in the packaging with each piece of approved terminal equipment.

A plug and jack used to connect this equipment to the premises wiring and telephone network must comply with the applicable FCC part 68 rules and requirements adopted by the ACTA. A compliant telephone cord and modular plug is provided with this product. It is designed to be connected to a compatible modular jack that is also compliant. See installation instructions for details.

The REN is used to determine the number of devices that may be connected to a telephone line. Excessive RENs on a telephone line may result in the devices not ringing in response to an incoming call. In most but not all areas, the sum of RENs should not exceed five (5.0). To be certain of the number of devices that may be connected to a line, as determined by the total RENs, contact the local telephone company. The REN for this product is part of the product identifier that has the format US: 2X6ND01BOL3000NNN. The digits represented by 01 are the REN without a decimal point (e.g., 03 is a REN of 0.3). The REN is separately shown on the label too.

If this equipment OL3000 causes harm to the telephone network, the telephone company will notify you in advance that temporary discontinuance of service may be required. But if advance notice isn't practical, the telephone company will notify the customer as soon as possible. Also, you will be advised of your right to file a complaint with the FCC if you believe it is necessary.

The telephone company may make changes in its facilities, equipment, operations or procedures that could affect the operation of the equipment. If this happens the telephone company will provide advance notice in order for you to make necessary modifications to maintain uninterrupted service.

Please follow instructions for repairing if any (e.g. battery replacement section); otherwise do not alternate or repair any parts of device except specified.

Connection to party line service is subject to state tariffs. Contact the state public utility commission, public service commission or corporation commission for information.



NOTICE: If your home has specially wired alarm equipment connected to the telephone line, ensure the installation of this OL3000 does not disable your alarm equipment. If you have questions about what will disable alarm equipment, consult your telephone company or a qualified installer.

Should you experience trouble with this equipment, please contact US Returns Center, Wave Industries, with the below information for warranty information. If the equipment is causing harm to the telephone network, the telephone company may request that you disconnect the equipment until the problem is resolved.

**QUESTIONS????? OUR HELPLINE IS**

**1-866-537-0384**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**WARNING:** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is needed.
- Consult the dealer or an experienced radio TV technician for help.

**WARRANTY**

This warranty covers any defect in material or workmanship for a period of one year from date of purchase. At our option we will repair or replace your unit.

To enforce warranty call Wave Customer Service at **866.537.0384** for a return authorization. Upon receipt of authorization pack your unit properly including all cables and accessories included with your original purchase. Include in the packaging a copy of the original sales receipt or other evidence of date of original purchase. Print your name and address, along with a description of the defect and include this in the package. Please include payment for any service or repair not covered by warranty, as determined by Wave Industries.

Ship the unit via a trackable method to:

**Wave Industries  
123 SE Second Ave.  
Portland, OR 97214**

Warranty does not cover batteries, damage from misuse or neglect, or acts of nature (lightning, floods, power surges, etc.) It also does not cover units, which have been modified or incorporated into other products, units which have been serviced by a facility not expressly authorized by Wave, or products purchased more than 12 months previous.

This warranty gives you specific rights. You may also have other rights which vary from state to state.